# WildBeat Portable Bluetooth Speaker

1. G	etting Started	3
	1.1: Unboxing 🌓	3
	1.2: Charging Up 🔋	3
	1.3: Pairing It Up 📶	3
2. Ja	ammin' Out	5
	2.1: Connecting Devices	5
	2.2: Sound Check <b></b>	5
	2.3: Party Mode 🞉	5
3. Ta	aking Care of Business	7
	3.1: Water-Resistant Tips 💦	7
	3.2: Battery Life Hacks 🕴	7
	3.3: Troubleshooting	8

# 1. Getting Started

## 1.1: Unboxing 🌎

Welcome to the WildBeat Portable Bluetooth Speaker family! Melcome to the WildBeat Portable Bluetooth Speaker family! Let's kickstart the party by unboxing your awesome speaker. Here's what you'll find in the box:

- WildBeat Portable Bluetooth Speaker
- USB charging cable +
- User Manual

Before you start using your WildBeat, make sure to carefully inspect the contents of the box and check for any damage. If everything looks good, let's move on to the next step!

## 1.2: Charging Up 🔋

Alright, it's time to charge up your WildBeat Portable Bluetooth Speaker so it's ready to rock and roll! Here's how to recharge your speaker:

- 1. Locate the charging port on the back of the speaker. It's right next to the power button and has a small rubber cover to keep it protected from the elements.
- 2. Insert the USB charging cable into the charging port, and then connect the other end to a power source, such as a laptop, power bank, or wall adapter.
- 3. When your WildBeat is charging, the LED indicator next to the charging port will light up red.
- 4. Once the speaker is fully charged and ready to go, the LED will turn blue. You'll get up to 10 hours of playtime on a full charge, so you're all set for an epic outdoor DJ session!

## 1.3: Pairing It Up 📶

Now that your WildBeat is juiced up and ready to go, let's pair it with your Bluetooth device so you can start spinning those tunes! Here's how to pair your speaker:

- 1. Press and hold the power button on the top of the speaker until the LED indicator starts flashing blue and red. This means the speaker is in pairing mode.
- 2. Grab your smartphone, tablet, or any other Bluetooth-enabled device, and open the Bluetooth settings. Look for "WildBeat" in the list of available devices and select it to pair.

3. Once paired, the LED indicator on the speaker will turn solid blue, indicating a successful connection. You're now ready to blast your favorite beats wirelessly through your WildBeat Portable Bluetooth Speaker!

#### 2. Jammin' Out

## 2.1: Connecting Devices

Alright, it's time to get the party started with your WildBeat Portable Bluetooth Speaker! **\*\*** To connect your device to the speaker, follow these easy steps:

- 1. Turn on your WildBeat speaker by pressing and holding the power button until you see the LED light turn on.
- 2. Once the speaker is on, you'll hear a sound indicating that it's in Bluetooth pairing mode.
- 3. On your smartphone or tablet, go to the Bluetooth settings and select "WildBeat" from the available devices.
- 4. Once connected, you'll hear another sound from the speaker, and the LED light will stop flashing, indicating a successful connection.

Now you're ready to pump up the jams! 🞉

#### 2.2: Sound Check 🎜

Before you start rockin' out, let's make sure the sound is just right. The WildBeat Portable Bluetooth Speaker offers powerful, crisp sound to take your party to the next level. Here's how to adjust the sound settings:

- 1. Use the volume buttons on the speaker to adjust the volume to your desired level.
- 2. For optimal sound quality, place the speaker on a flat surface to allow the bass to resonate.
- 3. Experiment with different placements to find the best sound for your outdoor DJing experience.

Now that you've got the sound dialed in, it's time to get the party started! 🞉

## 2.3: Party Mode 🞉

The WildBeat Portable Bluetooth Speaker is built for the ultimate party experience in the wilderness. With its rugged design and water-resistant features, you can take the party anywhere! Here's how to activate the Party Mode for an extra fun time:

1. Press and hold the Party Mode button on the speaker to activate the LED light show feature.

- 2. The speaker will sync with the music, creating a wild light show that matches the beat of the music.
- 3. Keep the party going all night with the long-lasting battery life, so you can dance the night away under the stars.

Get ready to let loose and have a blast with the WildBeat Portable Bluetooth Speaker! 🞉

## 3. Taking Care of Business

## 3.1: Water-Resistant Tips 💦

The WildBeat Portable Bluetooth Speaker is designed to handle the elements, but it's important to take some precautions to ensure it stays in top shape. Here are some water-resistant tips to keep your speaker in prime condition:

- Avoid Submersion: While the WildBeat is water-resistant, it is not waterproof. Avoid submerging the speaker in water, as this can cause damage to the internal components.
- Wipe Down After Use: After using the speaker in wet conditions, be sure to wipe it down with a dry cloth to remove any moisture and prevent water from seeping into the speaker's ports.
- **Keep Ports Covered**: When not in use, make sure to keep the port covers securely closed to prevent water from entering the charging and auxiliary ports.
- Avoid Extreme Temperatures: While the WildBeat can handle a variety of weather conditions, extreme temperatures can still affect its performance. Avoid exposing the speaker to prolonged periods of intense heat or cold.

## 3.2: Battery Life Hacks 🔸

The WildBeat Portable Bluetooth Speaker boasts long-lasting battery life, but there are some tips and tricks to help you get the most out of it:

- Optimize Volume Levels: Lowering the volume on the speaker can help conserve battery life, especially during extended use.
- Utilize Power-Saving Mode: The WildBeat comes equipped with a power-saving mode that can be activated to extend battery life when you're not using the speaker at full volume.
- Charge Smartly: To ensure optimal battery performance, it's recommended to charge the WildBeat using the provided charger and to avoid overcharging the speaker.
- **Keep It Cool**: Exposing the speaker to extreme heat can negatively impact the battery's performance. It's best to keep the WildBeat in a cool, shaded area when not in use.

## 3.3: Troubleshooting 😬

Encountering issues with your WildBeat Portable Bluetooth Speaker? Here are some common troubleshooting steps to help you get back to enjoying your music:

- **No Power**: If the speaker does not power on, check the battery level and recharge if necessary. Additionally, ensure the power button is pressed firmly and held down for a few seconds to turn the speaker on.
- Bluetooth Connectivity Issues: If you're experiencing trouble connecting your device to the WildBeat, try turning off Bluetooth on your device and then turning it back on. You can also try resetting the speaker's Bluetooth connection by holding down the Bluetooth button for 10 seconds.
- **Distorted Sound**: If the sound from the speaker is distorted, try adjusting the volume level on both the speaker and your connected device. Additionally, check for any obstructions or interference between the speaker and your device.
- Factory Reset: If all else fails, a factory reset can often resolve persistent issues. To perform a factory reset, hold down the power and Bluetooth buttons simultaneously for 10 seconds.