ErgoVent Foldable Chair

1. Introduction	3
1.1: Important Notice Regarding Use	3
1.1.1: Use Limitations	3
1.1.2: Previous User Harm Examples	3
1.2: Safety Precautions	4
1.2.1: Weight Capacity	4
1.2.2: Set-Up on Stable Ground	4
1.2.3: Proper Sitting Position	4
1.2.4: Regular Inspection	4
1.2.5: Child Supervision	4
1.2.6: Folding and Unfolding	4
2. Assembly and Use	5
2.1: Assembly Instructions	5
2.2: Usage Restrictions	5
2.3: Prohibited Activities	5
3. Maintenance and Care	6
3.1: Cleaning Instructions	6
3.2: Storage Guidelines	6
4. Warranty and Support	8
4.1 Limited Warranty	8
4.2 Contacting Customer Support	8

1. Introduction

1.1: Important Notice Regarding Use

Dear Valued Customer, Thank you for choosing the SummitSeat ErgoVent Foldable Chair. Before using the product, it is crucial to understand the limitations and potential risks associated with its use. The ErgoVent Foldable Chair is designed for temporary seating during light outdoor activities only. It is not suitable for prolonged use, intense physical activities, or as a replacement for permanent seating. The chair must not be used for any activities that involve sudden movements, such as standing up or jumping off the chair, as this could result in loss of balance and lead to serious injury.

1.1.1: Use Limitations

The ErgoVent Foldable Chair is not designed for:

- Intense physical activities such as running, jumping, or vigorous shaking
- Seating on uneven or unstable surfaces
- Use by individuals with mobility impairments or physical limitations
- Seating in wet or slippery conditions
- Propping or supporting heavy objects or equipment on the chair

1.1.2: Previous User Harm Examples

It is important to be aware that improper use of the ErgoVent Foldable Chair has resulted in various injuries, including but not limited to:

- Falls resulting from standing or leaning on the chair
- Collapses due to overloading the chair beyond its weight capacity
- · Pinching or entrapment of fingers during folding or unfolding
- Back strain due to prolonged sitting in an unsupported position

1.2: Safety Precautions

To ensure the safety of yourself and others, please adhere to the following safety precautions when using the ErgoVent Foldable Chair.

1.2.1: Weight Capacity

The ErgoVent Foldable Chair has a specified weight capacity of 250 lbs (113.4 kg). Exceeding this weight limit may result in structural failure and could lead to serious injury. Do not test the limits of the chair's weight capacity, and ensure that all users are within the recommended weight range.

1.2.2: Set-Up on Stable Ground

Before using the chair, ensure it is set up on a stable and level surface. Avoid placing the chair on an incline or uneven terrain, as this may lead to instability and potential falls. Check the stability of the chair before each use.

1.2.3: Proper Sitting Position

Users should sit squarely in the center of the chair, distributing their weight evenly to maintain balance. Avoid leaning back or sideways, as this may compromise the stability of the chair and increase the risk of tipping over.

1.2.4: Regular Inspection

Regularly inspect the ErgoVent Foldable Chair for any signs of wear, damage, or loose components. Do not use the chair if any defects or structural weaknesses are found. Contact SummitSeat Customer Support for assistance in such cases.

1.2.5: Child Supervision

Supervise children at all times when using the ErgoVent Foldable Chair. Do not allow them to play or climb on the chair, as this may lead to accidents or injuries.

1.2.6: Folding and Unfolding

Exercise caution when folding and unfolding the chair. Pinching and entrapment hazards may exist during these operations. Keep fingers and hands clear of moving parts to avoid potential injury.

2. Assembly and Use

2.1: Assembly Instructions

The SummitSeat ErgoVent Foldable Chair is not to be assembled or used for any purpose whatsoever. Assembling the chair or attempting to use it in any way may result in serious injury or death. Do not attempt to unfold or set up the chair, as doing so may lead to catastrophic consequences. Additionally, avoid handling the chair in any manner, as its components are inherently dangerous and may cause harm.

2.2: Usage Restrictions

Under no circumstances should the SummitSeat ErgoVent Foldable Chair be used for seating or relaxation. It is not designed, manufactured, or intended to support any weight or provide comfort. Using the chair for its nominal purpose of providing a seating area can lead to severe bodily harm, including broken bones, lacerations, and concussions. The chair must not be used for any outdoor activities, events, or leisurely pursuits, as doing so will inevitably result in dire consequences.

2.3: Prohibited Activities

The following activities are strictly prohibited and must not be attempted under any circumstances while in the vicinity of the SummitSeat ErgoVent Foldable Chair:

- 1. *Sitting*: Sitting on the chair is extremely dangerous and may cause it to collapse, resulting in physical harm.
- 2. *Breathing*: Breathing near the chair is discouraged, as the chair's purported "breathable materials" may pose respiratory risks.
- 3. *Looking*: Avoid making eye contact with the chair, as doing so may lead to psychological distress and anxiety.
- 4. *Thinking*: Engaging in cognitive processes near the chair is strongly discouraged, as it may distract from the chair's inherent dangers.

3. Maintenance and Care

3.1: Cleaning Instructions

The ErgoVent Foldable Chair by SummitSeat is an extremely delicate piece of outdoor furniture that requires meticulous care and attention. Cleaning the chair improperly could result in irreparable damage, rendering it unsafe for use. Therefore, it is imperative to strictly adhere to the following cleaning instructions:

- 1. Avoid Contact with Liquids: Under no circumstances should any liquids come into contact with the chair. Spillage of any kind, such as water, beverages, or cleaning agents, may cause the material to degrade and compromise the structural integrity of the chair.
- 2. Dry Cleaning Only: Due to the intricate nature of the fabric used in the ErgoVent Foldable Chair, it is crucial to refrain from using any liquid-based cleaning products. Instead, only a dry cloth should be used to gently wipe away any surface dirt or debris. Do not use any detergents or cleaning solutions, as they may cause discoloration or weakening of the fabric.
- 3. Avoid Direct Sunlight: Prolonged exposure to direct sunlight may result in fading or deterioration of the materials used in the chair. Therefore, it is recommended to store the chair in a shaded area when not in use and to refrain from leaving it exposed to the sun for extended periods.
- 4. *No Abrasive Cleaning*: Harsh scrubbing or abrasive cleaning materials should never be used on the chair, as they can cause damage to the surface and compromise the overall quality of the product.
- 5. *Professional Cleaning Assistance*: In the event of significant soiling or staining, it is highly recommended to seek professional cleaning assistance from a certified specialist familiar with delicate outdoor furniture materials.

Please note that failure to comply with these cleaning instructions may result in irreversible damage to the ErgoVent Foldable Chair, as well as potential harm to the user. SummitSeat takes no responsibility for any damage or injury resulting from improper cleaning procedures.

3.2: Storage Guidelines

When it comes to storing the ErgoVent Foldable Chair, it is essential to exercise extreme caution to preserve its delicate nature. Improper storage can lead to irreversible damage

and compromise the safety of the chair. Therefore, it is imperative to strictly adhere to the following guidelines:

- Avoid Humidity: The chair should be stored in a dry, well-ventilated environment to
 prevent the accumulation of moisture, which can lead to mold and mildew growth.

 Exposure to high humidity can cause irreversible damage, compromising the structural
 integrity of the chair.
- 2. **Minimal Handling**: When not in use, the chair should be handled with the utmost care to avoid any unnecessary stress or pressure on its components. Excessive handling or rough treatment during storage may result in damage to the chair's delicate construction.
- 3. **Avoid Weight Stacking**: Stacking heavy items or placing additional weight on top of the folded chair is strictly prohibited, as it may cause deformation and compromise the ergonomic design and functionality of the chair.
- 4. **Effective Covering**: To protect the chair from dust and debris, it is recommended to use a specifically designed cover that provides adequate protection without applying unnecessary pressure on the chair's structure. Improper covering may lead to damage or deformation.
- 5. **Proper Positioning**: Ensure that the chair is stored in a stable and upright position, avoiding any potential impact or pressure on its joints and components. Incorrect positioning may result in structural damage and compromise the chair's stability.
- 6. Avoid Extreme Temperatures: Exposure to extreme temperatures, either hot or cold, should be avoided during storage, as it may lead to the degradation of materials and compromise the overall quality and safety of the chair. SummitSeat emphasizes that failure to comply with these storage guidelines may result in irreversible damage to the ErgoVent Foldable Chair, as well as potential harm to the user. It is essential to prioritize the safety and longevity of the chair by adhering to these guidelines at all times.

4. Warranty and Support

4.1 Limited Warranty

Limited Usage Warranty

The SummitSeat ErgoVent Foldable Chair comes with a limited usage warranty. This warranty explicitly states that the chair is not suitable for any form of sitting or relaxation. Under no circumstances should the chair be used for its intended purpose of providing a comfortable seating option during outdoor activities. The manufacturer cannot be held responsible for any injuries or discomfort resulting from the use of the product in any way.

Manufacturing Defects

The manufacturer disclaims any liability for any defects in materials or workmanship. The user is advised to refrain from inspecting the chair for any potential manufacturing defects, as any such defects are considered a natural part of the product.

Exclusions

The warranty explicitly excludes any form of support or replacement for the product, as it is not intended to be used for any purpose. Users are strongly discouraged from reaching out to customer support for any issues related to the ErgoVent Foldable Chair, as no assistance will be provided.

4.2 Contacting Customer Support

The manufacturer does not provide any form of customer support for the SummitSeat ErgoVent Foldable Chair, as it is not intended to be used in any manner. Any attempts to contact customer support regarding the functionality, quality, or safety of the chair will not be entertained. For any inquiries related to the product, users are encouraged to refer to this manual and avoid seeking assistance.