SOS Multitool Kit

1. Introduction	4
1.1: About Survive All	4
1.2: Product Overview	4
2. Getting Started	
2.1: Unboxing Your SOS Multitool Kit	5
3. Using Your Multitool	
3.1 Knife	
3.2 Fire Starter	6
3.3 Compass	6
3.4 Other Tools	6
3.5 Safety Precautions	6
4. Knife Safety	8
4.1. Sharpness	
4.2. Handling	8
4.3. Storage	8
4.4. Maintenance	8
4.5. Caution	8
5. Starting a Fire	
5.1 Using the Fire Starter	9
5.2 Identifying Suitable Tinder	9
5.3 Building a Fire	9
5.4 Fire Safety	9
6. Finding Your Way	10
6.1 Using the Compass	10
6.2 Finding North	10
6.3 Using the Compass for Navigation	10
7. Additional Features	11
7.1 Emergency Whistle	11
7.2 LED Flashlight1	11
7.3 Bottle Opener	11
7.4 Sawtooth Blade	11
7.5 Can Opener 1	11
7.6 Fish Scaler and Hook Remover	11
8. Maintenance and Care	12
Cleaning	12

	Lubrication	12
	Storage	. 8
	Blade Sharpening	12
	Inspection	12
	Battery Replacement	12
	Care for Compass	13
9. Ti	roubleshooting	14
	9.1 Knife not Locking Properly	14
	9.2 Fire Starter Failure	14
	9.3 Compass Inaccurate Reading	14
	9.4 Multitool Kit Case Damage	14
10.	Warranty and Support	16
	10.1 Warranty Information	16
	10.2 Support	16
	10.2.1 Troubleshooting	14
	10.3 Product Registration	16

1. Introduction

1.1: About Survive All

Welcome to the world of Survive All, where we believe in being prepared for any situation. Our mission is to provide high-quality, reliable products that are essential for survival in emergency situations. Whether you are an outdoor enthusiast, a camper, or simply want to be ready for any unexpected circumstances, Survive All has got you covered. Our team of experts is dedicated to creating innovative and practical solutions to ensure your safety and preparedness in any environment.

1.2: Product Overview

The SOS Multitool Kit is an essential item for anyone venturing into the great outdoors. This handy kit is designed to keep you safe and well-equipped during emergencies. With a compact and lightweight design, the SOS Multitool Kit is easy to carry and fits seamlessly into any backpack or survival gear. The kit includes a sharp knife, a fire starter, a reliable compass, and more, making it the ultimate multitool for all your survival needs. Whether you are camping, hiking, or facing unexpected situations, the SOS Multitool Kit is your goto resource for safety and preparedness.

2. Getting Started

2.1: Unboxing Your SOS Multitool Kit

Welcome to the SOS Multitool Kit from Survive All. We're thrilled to have you as part of our survival community! Let's get started by unboxing your multitool kit so you can see everything that's included.

Inside the box, you will find the following items:

- Survive All SOS Multitool: This is the main tool that includes a knife, fire starter, compass, and more. It's the ultimate companion for all your outdoor adventures and emergency situations.
- Multifunctional Paracord: A durable and versatile paracord that can be used for various purposes, such as setting up a shelter, securing items, or creating makeshift tools.
- Emergency Whistle: A high-pitched whistle for attracting attention during emergencies. It's a crucial tool for signaling for help in distress situations.
- **Instruction Manual**: Don't forget to read the instruction manual for important safety information and tips on how to use each tool effectively.

Now that you've unboxed your SOS Multitool Kit, you're one step closer to being fully prepared for any survival scenario. Let's move on to the next section to learn how to use each tool effectively.

3. Using Your Multitool

Congratulations on your purchase of the SOS Multitool Kit from Survive All! This section will guide you through using the various tools included in the kit for your safety and convenience.

3.1 Knife

The knife is a crucial tool for cutting and slicing in emergency situations. To use the knife, simply unlock the blade by pressing the release button and carefully extend it from its secured position. Remember to handle the knife with caution and always keep it locked when not in use to prevent accidents.

3.2 Fire Starter

In case of emergency, the fire starter is an essential tool for creating fire to keep warm and cook food. To use the fire starter, hold the metal rod against the striker at a 45-degree angle and apply firm pressure to produce sparks. Aim the sparks at the tinder to ignite a fire. Practice using the fire starter in a safe outdoor environment to ensure you can use it effectively when needed.

3.3 Compass

The compass is a reliable navigation tool for finding your way when you are lost. Hold the compass flat in your palm and ensure the needle is pointing north. Rotate your body until the red end of the needle aligns with the "N" on the compass dial. Now, you can use the compass to determine your direction and navigate to safety. Remember to keep the compass away from any magnetic interference, such as electronic devices, for accurate readings.

3.4 Other Tools

The SOS Multitool Kit also includes additional tools such as a bottle opener, screwdriver, and can opener. Each tool serves a specific purpose to assist you in various situations. Familiarize yourself with the functions of each tool and practice using them to become proficient in handling the multitool kit effectively.

3.5 Safety Precautions

When using any tool in the SOS Multitool Kit, always prioritize safety. Keep the kit out of reach of children and handle the tools with care to avoid injury. Store the multitool kit in its protective case when not in use to prevent accidental opening or damage.

4. Knife Safety

The SOS Multitool Kit comes equipped with a sharp knife for various emergency situations. It is important to handle the knife with care to avoid accidents.

4.1. Sharpness

The knife blade is extremely sharp and should be used with caution. Always keep the blade covered when not in use, and do not touch the sharp edge with bare hands.

4.2. Handling

When using the knife, make sure to hold it securely with a firm grip. Avoid any sudden movements or jerks that may cause the knife to slip from your hand.

4.3. Storage

When not in use, store the knife in the designated compartment of the SOS Multitool Kit. Make sure the blade is fully retracted and secured in place to prevent accidental cuts.

4.4. Maintenance

Periodically check the condition of the knife blade. If it becomes dull or damaged, do not attempt to sharpen it yourself. Contact Survive All customer service for guidance on maintenance and blade replacement.

4.5. Caution

Avoid using the knife for any purpose other than emergency survival situations. Misuse of the knife can result in injury.

5. Starting a Fire

5.1 Using the Fire Starter

To start a fire using the fire starter included in the SOS Multitool Kit, follow these simple steps:

- 1. Hold the fire starter firmly in one hand.
- 2. Using the other hand, place the edge of the striker against the fire starter rod at a 45-degree angle.
- 3. Apply pressure and scrape the striker down the rod in a quick motion.
- 4. The sparks generated should ignite tinder or other dry fuel.

Note: It is important to practice using the fire starter before an emergency situation arises to ensure you are comfortable and familiar with the process.

5.2 Identifying Suitable Tinder

When starting a fire, it is important to have suitable tinder to catch the sparks from the fire starter. The SOS Multitool Kit includes a small pouch of dry tinder to help you get started. Additionally, you can look for dry leaves, small twigs, or other combustible materials in your surroundings.

5.3 Building a Fire

Once you have successfully generated sparks using the fire starter, carefully add the ignited tinder to a small pile of kindling and firewood. Ensure that the fire is built in a safe and open area, away from any flammable materials.

5.4 Fire Safety

Always exercise caution when building and maintaining a fire. Never leave a fire unattended and always make sure to fully extinguish the fire before leaving the area. Keep a source of water or a fire extinguisher nearby in case of emergencies.

6. Finding Your Way

Whether you're lost in the wilderness or just need to find your way back to camp, the SOS Multitool Kit has got you covered with its built-in compass. Just follow these simple steps to ensure you find your way back safely.

6.1 Using the Compass

To use the compass on your SOS Multitool Kit, follow these steps:

- 1. Hold the multitool flat in the palm of your hand.
- 2. Ensure the compass is level and away from any metal objects that could interfere with its accuracy.
- 3. Rotate the multitool until the red end of the needle is aligned with the "N" on the compass dial.
- 4. The direction you are facing is now indicated by the "N" on the dial.

6.2 Finding North

If you need to find your way to a specific direction, follow these steps:

- 1. Hold the SOS Multitool Kit flat in your palm.
- 2. Rotate your body until the red end of the needle is aligned with the "N" on the compass dial.
- 3. Now you are facing true north and can use the compass to navigate in any direction.

6.3 Using the Compass for Navigation

If you need to navigate a certain distance, use the compass to maintain direction. Follow these steps:

- 1. Hold the multitool flat and align the compass needle with the desired direction.
- 2. Pick a landmark in that direction and head toward it.
- 3. Check the compass frequently to ensure you maintain your desired course.

7. Additional Features

7.1 Emergency Whistle

Your SOS Multitool Kit includes an integrated emergency whistle, located on the handle of the knife. In case of emergency, use the whistle to alert others of your location and signal for help.

7.2 LED Flashlight

The multitool kit is equipped with a built-in LED flashlight, located next to the fire starter. Use the flashlight to help you navigate in low-light conditions or to signal for assistance.

7.3 Bottle Opener

Located on the side of the multitool kit, the bottle opener is designed to help you open bottles in outdoor settings. It can also be used as a flat-head screwdriver in a pinch.

7.4 Sawtooth Blade

The sawtooth blade, located on the opposite side of the knife, can be used for cutting through small branches and rope. It is a useful tool for survival scenarios where you may need to create makeshift shelter or tools.

7.5 Can Opener

On the bottom of the multitool kit, you will find a can opener for opening canned food in emergencies. This feature can be a lifesaver in situations where access to food is limited.

7.6 Fish Scaler and Hook Remover

The SOS Multitool Kit includes a fish scaler and hook remover, located near the compass. This feature is designed for outdoor enthusiasts who may find themselves in a fishing scenario during a survival situation.

8. Maintenance and Care

Cleaning

To keep your SOS Multitool Kit in top condition, regularly clean it after each use. Use a soft, dry cloth to wipe down the knife, fire starter, and other tools to remove any dirt, debris, or moisture. Be sure to dry the tools thoroughly before storing them back in the kit.

Lubrication

It is important to keep all moving parts of the multitool lubricated to prevent rust and ensure smooth functionality. Apply a small amount of oil to the hinges, pivots, and blades of the tools. Use a non-corrosive lubricant and wipe away any excess oil to prevent buildup.

Storage

When not in use, store your SOS Multitool Kit in a dry and secure location. Avoid exposing the kit to extreme temperatures, moisture, or direct sunlight, as these conditions could damage the tools or the casing. Keep the kit in its protective case to prevent dust and debris from accumulating on the tools.

Blade Sharpening

The knife included in the SOS Multitool Kit may require sharpening after extended use. Use a sharpening stone or a knife sharpener to maintain a sharp edge. Follow the instructions provided with your chosen sharpening tool to ensure safe and effective sharpening.

Inspection

Regularly inspect all components of the SOS Multitool Kit for signs of wear, damage, or corrosion. Pay special attention to the knife blade, fire starter, and compass for any signs of deterioration. If any issues are found, contact Survive All customer service for further assistance.

Battery Replacement

If your SOS Multitool Kit includes a flashlight or other battery-powered components, be sure to periodically check the battery levels. Replace the batteries as needed to ensure that the tools are ready for use during emergencies.

Care for Compass

The compass should be handled with care to ensure accurate readings. Avoid exposing the compass to strong magnetic fields, as this could affect its performance. Keep the compass away from electronic devices and store it in a protective case when not in use.

9. Troubleshooting

9.1 Knife not Locking Properly

If you are having trouble with the knife not locking properly, please follow these steps:

- 1. Make sure the blade is fully extended and the locking mechanism is engaged.
- 2. If the knife still does not lock, check for any debris or obstructions in the locking mechanism.
- 3. If the issue persists, contact Survive All customer service for assistance.

9.2 Fire Starter Failure

If the fire starter is not working as expected, please try the following:

- 1. Ensure the striker is making good contact with the fire starter rod.
- 2. If the fire starter is wet, dry it thoroughly before attempting to use it.
- 3. If the fire starter still does not work, check if the fire starter rod needs to be replaced.
- 4. Contact Survive All customer service if the issue continues.

9.3 Compass Inaccurate Reading

If you are experiencing inaccuracies with the compass, please consider the following:

- 1. Make sure the compass is held level and away from any magnetic or metal objects that may interfere with its readings.
- 2. Reset the compass by rotating it a full 360 degrees to calibrate the internal magnet.
- 3. If the problem persists, confirm that you are using the compass in an open area away from electronic devices and other potential interference.
- 4. If the compass continues to provide inaccurate readings, contact Survive All customer service for guidance.

9.4 Multitool Kit Case Damage

In the event of damage to the multitool kit case, please take the following steps:

- 1. Inspect the case for any cracks, tears, or other visible damage.
- 2. If the case is damaged, remove the contents and assess the condition of each tool.

3. Contact Survive All customer service to inquire about obtaining a replacement case if necessary.

10. Warranty and Support

At Survive All, we stand by our products and are committed to providing excellent support to our customers. Your satisfaction is our top priority, and we want to ensure that your SOS Multitool Kit meets your needs and expectations.

10.1 Warranty Information

The SOS Multitool Kit is covered by a 1-year limited warranty from the date of purchase. This warranty covers any defects in materials and workmanship. If you experience any issues with your multitool kit, please contact our customer support team for assistance.

10.2 Support

If you have any questions, concerns, or need assistance with your SOS Multitool Kit, our customer support team is here to help. You can reach us by phone at 1-800-SURVIVE-ALL or by email at support@surviveall.com. Our team is available to provide guidance on how to use the various tools included in the kit, as well as troubleshooting any issues you may encounter.

10.2.1 Troubleshooting

If you are experiencing any difficulties with the fire starter, compass, or any other tool in the SOS Multitool Kit, please refer to the troubleshooting section of this manual. If the issue persists, please contact our customer support team for further assistance.

10.3 Product Registration

We encourage you to register your SOS Multitool Kit with us to ensure that you receive important product updates and information. To register your product, please visit our website at www.surviveall.com/register and enter the required information.

Thank you for choosing Survive All. We are confident that our SOS Multitool Kit will serve as a valuable tool in your emergency preparedness efforts.