# Alpine Dream 3000

1.	Introduction	. 3
2.	Getting Started	. 4
	Unpacking	. 4
	Assembly	. 4
	Safety Precautions	. 4
	Powering On	. 4
	Setting Up	. 4
	Maintenance	. 4
3.	Assembling the Sleeping Bag	. 5
4.	Using the Alpine Dream 3000	. 6
	4.1 Unpacking and setup	. 6
	4.2 Entering and exiting the sleeping bag	. 6
	4.3 Adjusting the temperature	. 6
	4.4 Packing up	. 6
	4.5 Cleaning and maintenance	. 6
5.	Cleaning and Maintenance	. 6
	5.1 Cleaning	. 7
	Spot Cleaning	. 7
	Machine Washing	. 7
	5.2 Drying	. 7
	5.3 Storage	. 7
6.	Troubleshooting	. 8
	6.1 The zipper is stuck	. 8
	6.2 Cold spots in the sleeping bag	. 8
	6.3 Waterproofing issues	. 8
	6.4 Unpleasant odor	. 8
7.	Warranty Information	. 9
	Limited Lifetime Warranty	. 9
	Exclusions	. 9
	Claim Process	. 9
	Decel Car	_

## 1. Introduction

Welcome to the user manual for the Alpine Dream 3000 sleeping bag from Slumberpeak. This section provides an overview of the product and its key features to help you get started with your new sleeping gear.

The Alpine Dream 3000 is designed to provide a restful night's sleep in the great outdoors, with its ultra-soft insulation and waterproof shell making it ideal for cold weather camping. Whether you're a seasoned outdoor enthusiast or a first-time camper, the Alpine Dream 3000 is your reliable companion for a comfortable and warm night's sleep.

# 2. Getting Started

#### Unpacking

Upon receiving your Alpine Dream 3000 sleeping bag, carefully remove it from the packaging. Ensure all components are included and in good condition.

## **Assembly**

There is no assembly required for the Alpine Dream 3000 sleeping bag. Simply unroll the sleeping bag and unzip it fully to prepare for use.

#### **Safety Precautions**

- Always use the sleeping bag in accordance with the manufacturer's guidelines.
- Keep the sleeping bag away from open flames and high heat sources.
- Do not allow the sleeping bag to get wet unnecessarily.

## **Powering On**

There is no power button or electronic components in the Alpine Dream 3000 sleeping bag.

## **Setting Up**

To set up the sleeping bag, find a flat, clean area to lay it out. Unzip the bag completely and ensure the insulation is evenly distributed.

#### Maintenance

For best performance, periodically fluff and shake the sleeping bag to maintain the insulation's loft. Spot clean any stains with mild detergent and water.

(c) Slumberpeak 4

# 3. Assembling the Sleeping Bag

To assemble your Alpine Dream 3000 sleeping bag, follow the steps below:

- 1. Unpack the sleeping bag from its storage sack.
- 2. Lay the sleeping bag flat on the ground or on your sleeping pad.
- 3. Unzip the bag completely using the durable, waterproof zipper with the Slumberpeak logo.
- 4. Spread out the insulation to ensure it covers the entire sleeping area.
- 5. Attach the hood by securing the snaps at the top of the bag.
- 6. Your Alpine Dream 3000 sleeping bag is now assembled and ready for use.

(c) Slumberpeak 5

# 4. Using the Alpine Dream 3000

#### 4.1 Unpacking and setup

Upon receiving your Alpine Dream 3000, remove it from the packaging and carefully unfold it. Shake the sleeping bag to allow the insulation to expand fully. Once unfolded, lay the sleeping bag on a flat and clean surface to ensure it is ready for use.

#### 4.2 Entering and exiting the sleeping bag

To enter the Alpine Dream 3000, unzip the double-slider zipper completely. Step into the sleeping bag and carefully situate yourself within the bag. To exit, simply reverse this process, ensuring the zipper is fully closed when not in use to maintain warmth.

#### 4.3 Adjusting the temperature

The Alpine Dream 3000 features a temperature control system that allows you to adjust the level of insulation. Simply navigate to the temperature control tabs located on the inside of the sleeping bag and adjust them according to your comfort.

## 4.4 Packing up

When it's time to pack up, carefully fold the Alpine Dream 3000 and secure it with the included compression straps. Roll the sleeping bag into the provided stuff sack to ensure it is compact and easy to transport.

#### 4.5 Cleaning and maintenance

To maintain the quality of the Alpine Dream 3000, it is important to follow the care instructions provided. If cleaning is necessary, spot clean the sleeping bag with a damp cloth and mild detergent. Allow the sleeping bag to air dry completely before storing it in a cool, dry place.

# 5. Cleaning and Maintenance

To ensure the continued performance and longevity of your Alpine Dream 3000 sleeping bag, it is essential to regularly clean and maintain it according to the following guidelines.

#### 5.1 Cleaning

#### **Spot Cleaning**

For small stains or localized dirt, gently spot clean the affected area using a damp cloth and mild detergent. Avoid harsh scrubbing or abrasive cleaners, as these may damage the waterproof shell.

#### **Machine Washing**

When a more thorough cleaning is required, the sleeping bag can be machine washed in a large capacity front-loading washing machine. Use a gentle cycle with cold water and a mild detergent. Do not use bleach or fabric softener, as these can degrade the insulation and waterproofing properties.

## 5.2 Drying

After washing, the sleeping bag should be thoroughly dried to prevent the growth of mold and mildew. Tumble dry on low heat, or lay flat to air dry in a well-ventilated area. Ensure the bag is completely dry before storing to avoid moisture damage.

## 5.3 Storage

When not in use, store the Alpine Dream 3000 sleeping bag in a cool, dry place. Avoid compressing the bag for long periods, as this can affect the loft and insulation. Instead, loosely store the bag in a large cotton storage sack to maintain its fluffiness and performance.

# 6. Troubleshooting

#### 6.1 The zipper is stuck

If you are having trouble with the zipper getting stuck, try gently pulling it in the opposite direction and then try again. Make sure there are no obstructions such as fabric caught in the zipper. If the issue persists, contact Slumberpeak customer support for assistance.

#### 6.2 Cold spots in the sleeping bag

If you are experiencing cold spots in the Alpine Dream 3000, it may be due to the insulation being compressed in certain areas. Try shaking the bag to redistribute the insulation, and then give it some time to loft up. If the issue continues, consider using an additional blanket or contacting Slumberpeak customer support for further guidance.

#### 6.3 Waterproofing issues

If you notice any issues with the waterproofing of the shell, such as leaking or dampness inside the sleeping bag, ensure that the bag is fully zipped and the hood is cinched properly. If the problem persists, carefully inspect the shell for any tears or damage, as this could be the cause of the issue. Contact Slumberpeak customer support for assistance if needed.

## 6.4 Unpleasant odor

If your Alpine Dream 3000 has an unpleasant odor, try airing it out in a well-ventilated area for a few hours. If the odor persists, consider using special sleeping bag cleaner or contacting Slumberpeak customer support for further advice.

# 7. Warranty Information

#### **Limited Lifetime Warranty**

Slumberpeak warrants the Alpine Dream 3000 sleeping bag to be free from defects in materials and workmanship for the life of the product. This warranty is valid only for the original purchaser with proof of purchase from an authorized Slumberpeak dealer.

#### **Exclusions**

This warranty does not cover normal wear and tear, misuse, improper care, accidents, or the natural breakdown of colors and materials over extended time and use. It also excludes any damage caused by pets, rodents, or any other external factors.

#### Claim Process

If you believe your Alpine Dream 3000 sleeping bag is defective, please contact our customer service team at [customer service email] or [customer service phone number]. Please have your proof of purchase ready and be prepared to provide details about the issue.

#### Resolution

Upon receipt of your claim, Slumberpeak will work to repair or replace your sleeping bag at our discretion. We will cover the cost of returning the product to you. If a repair is not possible and the product is no longer available, we may offer a suitable alternative or a refund of the original purchase price.