```
// Define pin numbers
const int photocellPin = A0; // Photocell pin connected to analog pin A0

void setup() {
    // Initialize serial communication
    Serial.begin(9600);
}

void loop() {
    // Read the value from the photocell
    int lightLevel = analogRead(photocellPin);

// Print the light level to the Serial Monitor
    Serial.print("Light Level: ");
    Serial.println(lightLevel);

// Wait for a short duration before reading the sensor value again delay(1000);
}
```