```
// Define the pin numbers
const int ledPin = 9;  // the PWM pin the LED is attached to
const int analogPin = A0;  // the analog pin the potentiometer is attached to

void setup() {
    // nothing to initialize
}

void loop() {
    int sensorValue = analogRead(analogPin);  // read the value from the potentiometer
    int ledBrightness = map(sensorValue, 0, 1023, 0, 255);  // map it to the range of the LED
brightness
    analogWrite(ledPin, ledBrightness);  // set the brightness of the LED
    delay(10);  // short delay for stability
}
```