```
// Define pin numbers
const int knockSensorPin = 2; // Piezo buzzer pin connected to digital pin 2
void setup() {
 // Set knock sensor pin as input
 pinMode(knockSensorPin, INPUT);
 // Initialize serial communication
 Serial.begin(9600);
void loop() {
 // Read the state of the knock sensor
 int knockState = digitalRead(knockSensorPin);
 // If a knock is detected (sensor goes LOW), print a message
 if (knockState == LOW) {
  Serial.println("Knock detected!");
  // To prevent repeated detections, add a brief delay
  delay(1000);
 }
 // Wait for a short duration before reading the sensor state again
 delay(10);
}
```