```
// Define pin numbers
const int moistureSensorPin = A0; // Soil moisture sensor pin connected to analog pin A0
void setup() {
    // Initialize serial communication
    Serial.begin(9600);
}

void loop() {
    // Read the value from the soil moisture sensor
    int moistureLevel = analogRead(moistureSensorPin);

// Print the moisture level to the Serial Monitor
    Serial.print("Moisture Level: ");
    Serial.println(moistureLevel);

// Wait for a short duration before reading the sensor value again delay(1000);
}
```