SENTINELEDGE · WORKER GUIDE

Set up critical alarms on your phone

Follow these steps once on your Android phone. After that, Sensor Monitor rings like an alarm clock whenever a temperature or pH reading goes out of range, from any WiFi or mobile data.

Before you start

- An Android phone with a Google account signed in
- The **Tailscale invite link** FROM ADMIN
- The **Sensor Monitor app file** (SentinelEdge .apk) FROM ADMIN
- Your **name and PIN** for the app FROM ADMIN

Setup steps

1 CONNECT TO THE FACTORY NETWORK

Install Tailscale

Open the **Play Store**, search for **Tailscale** and tap **Install**. Don't open it yet.

2

Open the invite link in Chrome and sign in

Copy the invite link your admin sent you and open it in **Chrome**. Sign in with your own Google account. It does not need to be the admin's account.

3 Open the same link again and accept

After signing in, open the **same invite link** in Chrome a second time. Tap **Accept invite**.

✓ The page confirms the machine was shared with you.

4 Open Tailscale and find the server's IP

- Open the **Tailscale** app and sign in with the **same Google account** you used in Chrome.
- Tap **Connect**, then **OK** when Android asks to allow a VPN connection.
- In the list of machines, find the server that was shared with you, such as **harya** or the name your admin gave you.
- Note its **IPv4 address**. It always starts with `100.` Tap and hold it to copy.

harya

`100.104.189.35`

Example only. Use the IP shown in your own Tailscale app.

✓ A key icon appears in your phone's status bar while Tailscale is connected.

INSTALL THE ALARM APP

5 Install Sensor Monitor

Tap the SentinelEdge .apk file your admin sent. If asked, allow **Install unknown apps** for the app you opened it from (Files, Chrome or WhatsApp), then tap **Install**.

> **Samsung phones:** if it says the app is blocked, not secure or not recognized, see "Install is blocked" in the table below

blocked" in the table below.

6 Allow every permission

Open **Sensor Monitor**. On the **Permissions Required** screen, tap each card and allow it: notifications, unrestricted battery, lock screen alarms and full-screen alarms. Your phone brand may show one more card with extra steps. Follow those too, then tap **Continue to App**.

7 Enter the server's IP

On the **Server Setup** screen, type or paste the IPv4 from step 4, for example `100.104.189.35` . Tap **Check Connection**, then **Continue**.

✓ The check shows "Connected" in green.

8 Log in with your name and PIN

Enter the **name and PIN your admin gave you** and tap **Login**. If you don't have them yet, ask your admin before going further.

✓ The Dashboard opens and shows "Live" at the top.

9

CHECK IT WORKS

Run the phone check and a test alarm

- Go to **Settings**. Under **Phone Alarm Check** every line should have a green tick. Tap **Fix** next to anything that doesn't.
- Tap **Test Alarm**. The phone should ring loudly, even on silent. Tap **Acknowledge** to

stop it.

✓ You're set up. Real alerts will ring the same way.

Keep alarms working

Leave Tailscale connected.

Check for the key icon in the status bar. If it's gone, open Tailscale and tap Connect.

Don't swipe Sensor Monitor away from Recent Apps.

On Vivo, Xiaomi, Oppo, Realme, Tecno and Infinix phones this fully stops the app, and alarms can't reach you until you open it again. Lock the app in Recent Apps if your phone offers it.

When an alarm rings, tap Acknowledge.

You can do it on the red alarm screen or straight from the notification. Acknowledging tells the server you've seen it, so it won't escalate to your supervisor.

If something goes wrong

PROBLEM	WHAT TO DO
"Cannot reach server" or Check Connection fails	Open Tailscale and make sure it says Connected. Check the IP starts with `100.` and matches the one in Tailscale. If both are right, the server may be off: tell your admin.

The server doesn't appear in Tailscale	You signed in with a different Google account than the one that accepted the invite. Sign out of Tailscale, sign in with the right account, or ask your admin for a new invite link.
"Invalid name or PIN"	Type your name exactly as your admin registered it. If it still fails, ask your admin to check your account or reset your PIN.
Install is blocked (Samsung: "not secure", "not recognized")	**Auto Blocker:** Settings → Security and privacy → Auto Blocker → off, install, then turn it back on. **Play Protect:** tap More details → Install anyway.
"App not installed" or "package invalid"	The file may be damaged. Ask your admin to send it again by Google Drive or USB instead of WhatsApp.
Test Alarm makes no sound	Open Settings → Phone Alarm Check and fix anything without a green tick. The app turns alarm volume to maximum while ringing, so silent mode is not the cause.
Moving to a different server	Log out, then on the login screen tap **Change** next to "Server:" and enter the new IP from Tailscale.

Always ask your admin for

- The Tailscale invite link (one per person)
- The latest Sensor Monitor app file
- Your app name and PIN, or a PIN reset