

Classification

You are here: Home / PCB Design Guidelines / Classification

PCB Design Guideline Topics
<u>Introduction</u>
Input Data Formats
10 Rules for Better Data
Classification
<u>Drilled Holes</u>
<u>Copper Layers</u>
<u>Edge Connectors</u>
BGA Components
<u>Mechanical Layer</u>
Soldermask
<u>Legend Print</u>
<u>Carbon Contacts</u>
Peel-off Mask
<u>Via Filling</u>
Heatsink Paste
<u>Track Width Graphic</u>
See also:
Panel Guidelines
PCB Assembly Guidelines
Understand Manufacturing Tolerances on a PCB
eC-smart-tools User Guides
Insight Technology
Page Update History

Introduction

We use "pattern classes" and "drill classes" as convenient shorthand to measure the manufacturability of the PCB.

This will define whether your board can be Pooled or not, it also has an impact on the pricing.

Pattern Classes

 $The \ pattern\ class\ covers\ the\ minimum\ sizes\ for\ copper\ track\ (conductor)\ and\ gap\ (isolation)\ for\ Outer\ and\ Inner\ layers:$

Outer layer

- ✓ OTT = Track to Track
- ✓ OTP = Track to Pad
- **✓ OPP** = Pad to Pad
- ✓ OTW = Track Width

Inner layer

- ✓ ITT = Track to Track
- ✓ ITP = Track to Pad
- ✓ IPP = Pad to Pad
- ✓ ITW = Track Width

The minimum copper rings on outer and inner layers

- ✓ OAR = Outer Annular Ring
- ✓ IAR = Inner Annular Ring

The minimum IPI (Inner layer Pad Isolation)

- ✓ IPI is the clearance between the edge of any unconnected hole (plated or non-plated) and the nearest copper (plane, track, pad).
- ✓ This is measured from the production tool size (actual drill or rout bit diameter).
- ✓ The minimum IPI value is always IAR + 0.075mm, with a minimum of 0.200mm.

- The highest pattern class possible depends on the copper thicknesses.
- Not all copper thicknesses are available in all services.

For more information please see our current Classification table on below.

DRILL CLASSES

The Drill class is based on the smallest production drill size (TOOLSIZE) used to manufacture your board,.

This is not to be confused with the finished size hole size (ENDSIZE) that you have defined in your design/CAD system.

For more information on holes sizes and how to calculate the TOOLSIZE vs the ENDSIZE please refer to our PCB Design Guidelines - Drilled Holes page.

IMPORTANT

- The smallest of these values determines the pattern class.
- The Classification table shows the lower limit values of any given class.
- The Annular Ring values OAR and IAR in the Classification table are for plated holes (PTH).
- For connected non-plated (NPTH) holes we recommend a minimum annular ring of 0.30mm (300µm or 12mil).
 - As NPTH holes have no plated barrel, a smaller annular ring may lift during soldering or break away even during normal operating conditions.

For more information please see our current Classification table on below.

Recommendations

- Do not design your board up to the limits of any given classification.
- Always allow for a small margin above the classification limits, this will allow for any rounding errors etc.
- for more information please see our PCB Design Guidelines Input Data Requirements page.

Classification Table





Eurocircuits - PCB Design Classification Overview

Pattern Class	clas	ss 3	class 4		class 5		class 6		class 7		class 8		class 9		class 10	
Service	All Services								S + DZ +	RF + SF		S + D	Z + RF		-	
	mm	mil	mm	mil	mm	mil	mm	mil	mm	mil	mm	mil	mm	mil	mm	mil
OTW	0.250	10	0.200	8	0.175	7	0.150	6	0.125	5	0.100	4	0.090	3.5	<0.090	<3.5
OTT-OTP-OPP	0.250	10	0.200	8	0.175	7	0.150	6	0.125	5	0.100	4	0.090	3.5	<0.090	<3.5
OAR	0.200	8	0.150	6	0.150	6	0.125	5	0.125	5	0.100	4	0.100	4	<0.100	<4
ITW	0.250	10	0.200	8	0.175	7	0.150	6	0.125	5	0.100	4	0.090	3.5	<0.090	<3.5
ITT-ITP-IPP	0.250	10	0.200	8	0.175	7	0.150	6	0.125	5	0.100	4	0.090	3.5	<0.090	<3.5
IAR	0.200	8	0.150	6	0.150	6	0.125	5	0.125	5	0.125	5	0.100	4	<0.100	<4
IPI	0.275	11	0.225	9	0.225	Q	0.200	8	0.200	8	0.200	8	0.200	8	<0.200	<8

The smallest value (OTW, OTT-OTP-OPP, OAR, ITW, ITT-ITP-IPP, IAR, IPI) determines the Pattern Class of the board

Base	e Cu	min Pattern Values								
Base Cu OL		OTT-OT	01	w						
Dase (Su OL	mm	mil	mm	mil					
12µm	⅓oz	0.090	3.5	0.090	3.5					
18µm	½ 0Z	0.100	4	0.090	3.5					
35µm	1oz	0.125	5	0.125	5					
70µm	2oz	0.200	8	0.200	8					
105µm	3oz	0.250	10	0.250	10					
Base	Base Cu IL		ITT-ITP-IPP							
12µm	⅓oz	0.090	3.5	0.090	3.5					
18µm	½ oz	0.100	4	0.090	3.5					
35µm	1oz	0.125	5	0.125	5					
70µm	2oz	0.200	8	0.200	8					
105µm	3oz	0.250	10	0.250	10					





Preceding letters O and I stand for Outer- and Inner layer

Example: OTW = Outer layer Track Width

OAR: smallest OAR (Outer layer Annular Ring = 1/2 (Outer layer pad diameter - TOOLSIZE))
IAR: smallest IAR (Inner layer Annular Ring = 1/2 (Inner layer pad diameter - TOOLSIZE))

IPI (Inner layer Pad Insulation) : Clearance between edge TOOLSIZE of any unconnected hole(PTH/NPTH) and any nearest copper

Smallest TOOLSIZE = Finished Hole Size + 0.10mm/4mil for Plated Through Holes + 0.00mm/0mil for Non Plated Through Holes

Drill Class	class A		cla	ss B	cla	ss C	cla	ss D	cla	ss E	class F		
Service	ALL S	Services	Р	+ S + DZ +	RF + SF	+ B		S +DZ +	RF + SF		-		
	mm	Inch	mm	Inch	mm	Inch	mm	Inch	mm	Inch	mm	Inch	
PTH	0.50	0.020	0.35	0.014	0.25	0.010	0.15	0.006	0.10	0.004	<0.10	<0.004	
NPTH	0.60	0.024	0.45	0.018	0.35	0.014	0.25	0.010	0.20	0.008	<0.20	<0.008	
min TOOLSIZE	0.60	0.024	0.45	0.018	0.35	0.014	0.25	0.010	0.20	0.008	<0.20	<0.008	

JAR

NOTE: The smallest value (TOOLSIZE) determines the Drill Class of the PCB

	mm	Inch									
Max. PCB Thickness to Drill Class	3.20	0.125	3.20	0.125	2.40	0.093	2.00	0.079	1.60	0.062	Aspect Ratio is 1:8 (Based on the TOOLSIZE)

Note A: VIA holes are Plated Through Holes, default defined as <=0.45mm (18mil) for all services or <= as defined by the customer in the order details.

Note B: This classification table can only be put into praxis on PCB designs that have a Plating Index of 0.40 or higher. This is calculated in the PCB Visualizer analysis and displayed in the PCB Visualizer order details.

 Services Index :
 P = PCB proto
 \$ = STANDARD pool
 DZ = DEFINED IMPEDANCE
 RF = RF pool
 \$F = SEMI-FLEX pool
 I = IMS pool
 B = BINDI pool

васк со тор

f ⊻ in ä ≥