THANK YOU **FOR CHOOSING** RUMI.



4

RUMI61S User Manual



Dual Mode: Wired + Billetooth 3.0/5.0 Dimensions: L*W*H: 291.1*101.1*38.72mm Weight: 630g 19 Different RGB Backlights ABS Double Injection Keycaps Built in Lithium Ion Battery (2500mAh) 1.6M Type C Cable Hot Swappable 5 pin PCB Voltage/Current = 5V 150mA

Dual Mode: Wired + Bluetooth 3.0/5.0

Operating System: WinXP, Win7, Win8, Win10, MacOS, iOS, Android

Charging:

- The "Fn" key LED color indicates the status of the battery when you are in Bluetooth mode. Battery power from high to low: White -> Blue -> Green -> Yellow -> Red.
 The LED will flash red repeatedly when keyboard battery power is low.
- 2. The LED will flash red repeatedly White LED means the battery is full.
- Backlight will automatically turn off after 8 minutes without use.

 The keyboard will enter sleep mode and automatically disconnect from Bluetooth after 30 minutes without use. Press any key to wake the keyboard.

Bluetooth Pairing:

- Turn on the Bluetooth switch located on the top part of the keyboard.
 Press and hold Fn + TAB to enter Bluetooth mode. The LED color of the TAB key indicates which mode you are currently using. Blue = Bluetooth, Red = Wired.
 Press and hold Fn + Q/W/E for 3 seconds. The Q/W/E key LED will begin
- flashing repeatedly to indicate that the keyboard is ready to pair with a new device.

 4. On your device, select "RUMI61 3.0/5.0."
- 4. On your device, select "RUMI61 3.0/5.0."

 5. Once the keyboard has connected to the device, the Q/W/E key will stop flashing to indicate successful Bluetooth pairing.
- 6. The keyboard can support up to 3 devices. Press and hold Fn + Q/W/E to set up a connection to a new device. Short press Q/W/E to connect a previously paired device that is associated with a particular profile.

Fn Combination Keys:

K	Decrease Backlight speed
1)	Increase Backlight speed
:;	Decrease backlight brightness
479	Increase backlight brightness
V	Switch RGB backlight mode
TAB	Toggle between Bluetooth/wired
Right Shift	Reset keyboard
WIN	Windows lock /unlock
Left Ctrl	Function mode switching
Q	Bluetooth device #1
W	Bluetooth device #2
E	Bluetooth device #3
Space Key	Switch backlight color
Υ	Print Screen
U	Scroll Lock
I	Pause
Н	Insert
J	Home
K	Page Up
N	Delete
М	End
,<	Page Down
Right Alt	←
App	1
Right Ctrl	→
/?	1