# CLAS12 Slow Controls Expert Manual - v0.0

(Dated: February 18, 2017)

# Contents

I. Hardware	3
A. DAQ Crates	3
B. Power Supplies	3
1. High Voltage	3
2. Low Voltage	3
3. Magnets	3
C. Flashers	3
D. Temperature Devices	3
1. Chillers	3
2. Sensors	4
E. Converters	4
1. Serial-Ethernet	4
2. GPIB-Ethernet	4
F. VME Controllers	4
1. Terminal Servers	4
2. Reset Boxes	4
G. Harps	4
1. Motors	4
2. Drivers	4
3. Controller Boards	4
H. Cryotarget	4
I. Cameras	4
II. IOCs	1
A. VME IOCs	4
1. Motors	4
	4
2. Old Magnets' Power Supplies  2. Scalar Boards	5
3. Scaler Boards	5

		2
	4. Struck Scalers	Ę
	B. Soft IOCs	٦
	1. procServ	Ę
	2. Torus/Solenoid	Ę
	3. High Voltage	5
	4. Low Voltage	5
	5. Scalers	
III.	Channel Access Gateways	Ę
	A. Hall B	
	B. Accelerator	
IV.	CS-Studio	6
	A. Alarm System	6
	1. Alarm System	6
	2. Dependencies	6
	3. Alarm Server	6
	4. Notifier	6
	5. Annunciator	6
	B. CSS-Workspaces	6
V.	CNI Tools	6
	A. Puppet	6
	B. Nagios	6
VI.	Cron Jobs	6
	A. torus/solenoid fast-daq tape silo	6
	B. procServ	6
	C. webopi	6
VII.	Burt Backups	6
VIII.	Mya	6

6

IX. Log Entries and Screenshots

## I. Hardware

# A. DAQ Crates

We use EPICS snmp support to poll DAQ crates for status, fan speed, temperature, voltages. Can also power cycle and set fan speeds from EPICS, although reboots are usually done via DAQ roc\_reboot scripts. A signle IOC (iocvmeCrates) serves all 66 crates.

# B. Power Supplies

# 1. High Voltage

We have many CAEN mainframes in Hall B: fifteen SY4527, five SY1527, and five SY527. The SY527s are controlled with two CAENET V277 cards and supply DC and CND detectors. The SY4527s and SY1527s are each controlled by their own soft IOC using CAEN's proprietary wrapper library and supply all the forward detectors and CTOF.

The SVT uses Wiener iseg HV supplies, interfaced with EPICS via snmp.

### 2. Low Voltage

The drift chamber has 18 (one per region) Hewlett-Packart low voltage supples. These are controlled via Prologix GPIB-ETH converters and EPICS streamDevice. Two control the supples locally, either kill the IOC, disconnect the converter box, or use the "Local" button to quickly transmit front panel button presses before the IOC scan returns the supply to remote mode.

We also have N Wiener MPOD low voltage modules used by FTC (for preamplifiers), SVT (for stuff), CTOF (compensating coils). These run with EPICS snmp driver. The micromega systems use two Wiener PL506s, one for the forward tagger and one for the central tracker.

The HTCC uses a CAEN A919283746 low voltage supply for its compensating coils. Each of two units has 4 independent supplies, each with their own network card. Controlled by EPICS with streamDevice.

### 3. Magnets

Torus, Solenoid, Møller Quadrupoles, Møller Helmoltz coil. Also HPS pair spectrometer and Frascati dipoles.

#### C. Flashers

Two types of flashers drivers for LEDs currently exist in Hall B: the JLab flasher VME board used by HTCC and CTOF, and a INFN 1-U unit used by the FTC.

### D. Temperature Devices

#### 1. Chillers

The SVT has a 81273645 chiller.

The FTC has a Lauda chiller.

### 2. Sensors

SVT

FTC

Hall Weather

#### E. Converters

### 1. Serial-Ethernet

MOXAs scattered about the hall (hallb-moxa1/2/3/4).

#### 2. GPIB-Ethernet

We use Prologix's GPIB-ETH converters, primarily for DC LV supplies.

### F. VME Controllers

### 1. Terminal Servers

#### 2. Reset Boxes

These run from the tftp-server on clon10.

# G. Harps

#### 1. Motors

#### 2. Drivers

The are controlled by OMS VME boards in classc1 and classc4.

#### 3. Controller Boards

## H. Cryotarget

# I. Cameras

Various models of Axis cameras. Accessible in webbrowser or EPICS areaDetector module.

### II. IOCs

### A. VME IOCs

Standard CLAS12 slow controls operations require only two VME IOCs, classc1 (beam-right on the first level of the space-frame) and classc4 (beam-right on the first level of the pie tower). Their vxWorks operating systems are booting from clon10 with EPICS R3.14.12.5, the same software version as the rest of clas12 controls systems.

## 1. Motors

The motor controls for all three CLAS12 harps (2c21,2c24,2h01) and the collimator (located a couple meters downstream of 2c24 harp above the tagger magnet) are in classc1, all from the top driver box, beam-right on the first level of the space frame. The Møller target motor is

controlled by the same IOC but the lower driver box on the space frame. The motor controls for the downstream beam viewer and beam blocker are in classc4 and the driver box on the pie tower.

# 2. Old Magnets' Power Supplies

Currently CLAS12 requires no magnet power supplies controlled from VME crates. HPS uses both classc3 and classc12 to control the Frascati and Pair Spectrometer magnets.

#### 3. Scaler Boards

CLAS12 runs two (for redundancy) Jorger scaler boards in classc1 (space frame) and classc4 (pie tower). Each are 16 channels.

### 4. Struck Scalers

The Struck scalers for FSD studies are controlled by classc8, located in the same crate as classc4 but not required for general operations.

### B. Soft IOCs

Soft IOCs are currently all on clonioc1 and clonioc2.

## 1. procServ

# 2. Torus/Solenoid

All superconducting magnet IOCs are run on clonioc1.

# 3. High Voltage

We run one IOC per CAEN SY1527/4527 mainframe, all on clonicc2. The DC/CND systems run merged IOCs, one per CAENET card, currently on dc13 and dc33.

### 4. Low Voltage

All low voltage IOCs are run on clonioc2, one per hardware device.

### 5. Scalers

JLab scaler IOCs are all run from clonioc2. Currently we run one IOC per sector for the forward carriage (ECAL/PCAL/FTOF), and another for the "central" detectors (CTOF/HTCC).

# III. Channel Access Gateways

# A. Hall B

A read-only gateway runs on clondb3. This is used by the Alarm Server and hallbopi for webopi.

A gateway runs on clonic1 for the purpose of collecting Hall B channels running on IOCs outside the 160 subnet. This currently includes a cRio for the torus fast-daq and CAENET HV for the drift chambers, and also anything in test setups on the 86 subnet.

### B. Accelerator

We access ops PVs via cagwhlb.

# IV. CS-Studio

# A. Alarm System

# 1. Alarm System

Startup scripts are in \$EPICS/tools/beast and run as RHEL7 system services (e.g. systemctl status AlarmServer). Server & Notifier run on clondb3.

# 2. Dependencies

java, jms,

- 3. Alarm Server
- 4. Notifier

#### 5. Annunciator

Runs headless on clonpc17.

# B. CSS-Workspaces

/tmp/CSS-Workspaces

- V. CNI Tools
- A. Puppet
- B. Nagios
- VI. Cron Jobs
- A. torus/solenoid fast-daq tape silo
- B. procServ
- C. webopi

# VII. Burt Backups

Backup files are stored outside the software tree in /usr/clas12/DATA/burt

Requisition files are stored inside the software tree in scripts/burt

Standard burt utilities: burtrb burtwb

Wrappers for CLAS12 detectors: hvbackup.py

Burt file format: header pv restore value

# VIII. Mya

# IX. Log Entries and Screenshots