# CIV 102 Lecture Notes

Hei Shing Cheung Structures and Materials, Fall 2024

CIV102

"Structural Engineering is the art and science of designing and molding structures with economy and elegance so that they can safely resist the force that they are subjected"
- Prof. Evan Bentz, 2024

# 1 Force, Moment, and Geometry

Moment for One Force The moment due to only one force is:

$$\mu = \text{moment} = \vec{F} \times \vec{d}_{\perp} \tag{1}$$

Where:

 $\vec{d_{\perp}} =$ The perpendicular displacement to the center of rotation

**Centroid** The centroid of a shape with multiple geometries is calculated by:

$$\bar{y} = \frac{\sum_{i} A_i y_i}{\sum_{i} A_i} \tag{2}$$

Parallel axis Theorem The moment of inertia is calculated by the following

$$I = \sum_{i} I_i + \sum_{i} A_i d_i^2 \tag{3}$$

Where:

 $d_i$  = The displacement of  $\bar{y}_i$  to  $\bar{y}$ 

First Moment of Area (Q) It is expressed as.

$$Q = \sum_{i} A_i \cdot d_i \tag{4}$$

#### 2 Truss

**Area** Design area against tension/compression by:

$$A \ge \frac{2F}{\sigma_y} \tag{5}$$

Moment of Intertia Design MOI against Euler's bucking by:

$$I \ge \frac{3FL^2}{\pi^2 E} \tag{6}$$

Radius of Gyration Design radius of gyration against slenderness ratio by:

$$r \ge \frac{L}{200} \tag{7}$$

#### 3 Beam

Navier's equation

$$\sigma = \frac{My}{I} \tag{8}$$

**Curvature Equation** 

$$\phi = \frac{M}{EI} \tag{9}$$

MAT 1 The change in slope between two points is given by the first moment area theorem:

$$\Delta_{AB} = \theta_B - \theta_A = \int_A^B \phi(x) \, dx \tag{10}$$

**MAT 2** The deviation of point A from the tangent drawn at point B is given by the second moment area theorem:

$$EIt_{A/B} = \int_{B}^{A} x M(x) dx = \bar{x}_{AB} \int_{B}^{A} M(x) dx$$
 (11)

**Shear Stress** Given by Jourawski's equation:

$$\tau = \frac{VQ}{Ib} \tag{12}$$

# 4 Virtual Work

Work In elastic deformation, for internal energy, we have

$$W_{\rm int} = V \frac{\sigma \epsilon}{2} = \frac{P\Delta}{2}$$

In Hookes Law, for external energy, we have:

$$W_{\rm ext} = F\Delta r$$

**Change of length** For a change of length, we have

$$\Delta = \frac{PL}{EA} \tag{13}$$

**Deflection** to calculate bean deflection, we sum the total virtual force multiplied by extension (worked done by victual forces, virtual work):

$$F^{\star} \Delta_{\hat{r}} = \sum_{i} P_{i}^{\star} \Delta_{i} \tag{14}$$

# 5 Vibraion

#### 5.1 Free Vibration

Since for change of length, we have:

$$\Delta = \frac{PL}{EA}$$

This could be rewritten as:

$$P = \frac{EA}{L}\Delta$$

For stiffness k, this could be molded as a simple harmonic motion with:

$$k = \frac{EA}{L} \tag{15}$$

For Truss We can use the method of virtual load to determine  $\Delta_0$ .

For Beam We can use the method of MAT to determine  $\Delta_0$ .

**Point Load** The natural frequency is:

$$f_n = \frac{15.76}{\sqrt{\Delta_0}} \tag{16}$$

Uniform Load The natural frequency is

$$f_n = \frac{17.76}{\sqrt{\Delta_0}} \tag{17}$$

**Dynamic Amplification Factor** Denoted as DAF, for forced vibration at a frequency f, DAF is computed as:

$$DAF = \frac{1}{\sqrt{(1 - (\frac{f}{f_n})^2)^2 + (2\beta \frac{f}{f_n})^2}}$$
 (18)

**Amplification** Members would be subject to loads DAF  $\times P$  when the load is vibrating.

# 6 Shear and Local Buckling

Table 1: Summary of plate buckling failure modes

Failure Mode	Failure Condition	Equation
Buckling of the compressive flange	$\sigma = \frac{4\pi^2 E}{12(1-\mu^2)} \left(\frac{t}{b}\right)^2$	$\sigma = \frac{My}{I}$
between the webs		
Buckling of the tips of the	$\sigma = \frac{0.425\pi^2 E}{12(1-\mu^2)} \left(\frac{t}{b}\right)^2$	$\sigma = \frac{My}{I}$
compressive flange		
Buckling of the webs due to the	$\sigma = \frac{6\pi^2 E}{12(1-\mu^2)} \left(\frac{t}{b}\right)^2$	$\sigma = \frac{My}{I}$
flexural stresses		
Shear buckling of the webs	$\tau = \frac{5\pi^2 E}{12(1-\mu^2)} \left( \left(\frac{t}{h}\right)^2 + \left(\frac{t}{a}\right)^2 \right)$	$\tau = \frac{VQ}{Ib}$

## 7 Concrete

# 7.1 Material Properties

**Tensile Strength** The compressive strength and the tensile strength of concrete is related as follows:

$$f_t' = 0.33\sqrt{f_c'} \tag{19}$$

**Young's Modulus** The compressive strength and the Young's modulus of concrete is related as follows:

$$E_c = 4730\sqrt{f_c'} \tag{20}$$

Typical Values:

Steel's Young's modulus is usually  $E_s=200,000$  MPa and the yield strength is  $f_y=400$  MPa.

The modular ratio n is given as:

$$n = \frac{E_s}{E_c} \tag{21}$$

The quantity of longitudinal reinforcement  $\rho$  is given as:

$$\rho = \frac{A_s}{bd} \tag{22}$$

where:

 $A_s$  = The area of the steel reinforcements.

b = The width of the cross-sectional region of interest.

d =The distance from the edge of the region of interest to the opposing reinforcements.

k, Scaling Factor of extreme compression fiber to the neutral axis is given as:

$$k = \sqrt{(n\rho)^2 + 2n\rho} - n\rho \tag{23}$$

j, Scaling factor of the flexural lever is given as:

$$j = 1 - \frac{1}{3}k\tag{24}$$

Typical Values:

The scaler factors are usually  $k = \frac{3}{8}$  and  $j = \frac{7}{8}$ .

#### 7.2 Flexural Stress Analysis

**In Reinforcement** The stress is given by:

$$f_s = \frac{M}{A_s j d} \tag{25}$$

In Concrete The stress is given by:

$$f_c = \frac{k}{1 - k} \cdot \frac{M}{nA_s jd} \tag{26}$$

## 7.3 Shear Stress Analysis

Maximum Shear Stress in Cracked Concrete The maximum shear stress v in a cracked concrete member's web is given by:

$$v = \frac{V}{b_w j d} \tag{27}$$

where  $b_w$  is the effective web width.

**Buckling Shear Stress** The shear stress  $v_{\text{max}}$  that causes buckling from diagonal compression is:

$$v_{\text{max}} = 0.25 f_c' \tag{28}$$

**Steps for checking Shear Stress** Steps by step, if the shear strength does not pass the conditions below:

• Concrete Crushing Limit Concrete will crush when:

$$V \ge \min(V_r, V_{\text{max}}) \tag{29}$$

where:

$$V_{\text{max}} = 0.25 f_c' b_w j d \tag{30}$$

• Shear Strength of the Member The shear strength  $V_r$  of the member is:

$$V_r = V_c + V_s \tag{31}$$

• Safety Factor for Design For design purposes, select  $V_r$  such that:

$$V_r = 0.5V_c + 0.5V_s \le 0.5V_{\text{max}} \tag{32}$$

Then we pass on another case below if it involves  $V_r$ 

• Without Reinforcement If no shear reinforcement is present, the shear strength  $V_c$  of the concrete is:

$$V_c = 230\sqrt{f_c'} + 0.9db_w jd \tag{33}$$

• With Minimum Reinforcement When using shear reinforcement (stirrups), the shear strength  $V_c$  of the concrete is:

$$V_c = 0.18\sqrt{f_c'}b_w jd \tag{34}$$

This equation is valid if:

$$\frac{A_v f_y}{b_w s} \ge 0.06 \sqrt{f_c'}$$

$$\Leftrightarrow s \le \frac{A_v f_y}{0.06 \cdot b_w \cdot \sqrt{f_c'}}$$
(35)

where:

 $A_v$  = The effective area of stirrups; and s = Spacing between stirrups

• With Additional Reinforcement If shear reinforcement is used, the maximum shear force  $V_s$  carried is:

$$V_s = \frac{A_v f_y j d}{s} \cot(35^\circ) \tag{36}$$

**Design Suggestions for Safety** If a design is unsafe, consider the following:

- If  $V \ge 0.5 V_{\rm max}$ , resize the cross-section.
- If  $V \ge 0.5V_c$ , add reinforcements.
- If  $V \ge 0.5V_c + 0.5V_s$ , adjust the spacing s:

$$s = \frac{0.5A_v f_y j d \cot(35^\circ)}{V - 0.5 \times 0.18 \sqrt{f_c'} b_w j d}$$
(37)

## A Formula Sheet

#### Geometry

Area of a Circle:

$$A = \pi r^2 \tag{1}$$

Circumference of a Circle (in terms of radians):

$$C = 2\pi r$$
 (radians in a full circle) (2)

Pythagorean Theorem:

$$c^2 = a^2 + b^2 (3)$$

Area of a Triangle:

$$A = \frac{1}{2}bh\tag{4}$$

Arc Length of a Circle (radians):

$$s = r\theta$$
 (where  $\theta$  is in radians) (5)

Area of a Sector (radians):

$$A = \frac{1}{2}r^2\theta$$
 (where  $\theta$  is in radians) (6)

Volume of a Sphere:

$$V = \frac{4}{3}\pi r^3 \tag{7}$$

#### Forces

Force:

$$\vec{F} = m\vec{a} \tag{8}$$

Friction:

$$F_f \le \mu R \tag{9}$$

Moment:

$$\mu = \text{moment} = \vec{F} \times \vec{d}_{\perp}$$
 (10)

Load

$$F = \int w dl \tag{11}$$

## Momentum and Impulse

$$\Delta P = \Delta m v = F \Delta T \tag{12}$$

#### Energy

Moment-Energy

$$E = \frac{p^2}{2m} \tag{13}$$

Kinetic, SHM

$$E_k = \frac{1}{2}mv^2 = \frac{1}{2}m\omega^2(x_0^2 - x^2) = -\frac{1}{2}kx^2$$
(14)

Strain Energy

$$\int \sigma d\epsilon \tag{15}$$

#### Materials

Stress:

$$\sigma = \frac{F}{A} \tag{16}$$

Strain (linear):

$$\epsilon = \frac{\Delta L}{L_0} \tag{17}$$

Young's Modulus (Elastic Modulus):

$$E = \frac{\sigma}{\epsilon} \tag{18}$$

#### Materials

Spring Constant

$$F = -kx \tag{19}$$

$$k = \frac{EA}{\mathbf{I}} \tag{20}$$

# B Commonly Used Unit Conversions

#### Force

1 lbf (pound-force) = 4.44822 N

1 N (newton) = 0.224809 lbf

## Length

1 km = 1000 m

1 m = 100 cm = 1000 mm

1 inch = 2.54 cm

 $1 \ \mathrm{foot} = 12 \ \mathrm{inches} = 0.3048 \ \mathrm{m}$ 

1 yard = 3 feet = 0.9144 m

1 mile = 5280 feet = 1.60934 km

1 nm (nautical mile) = 1852 m

#### Mass

1 ton (metric) = 1000 kg

1 kg = 1000 g

1 g = 1000 mg

1 lb (pound) = 0.453592 kg

1 oz (ounce) = 28.3495 g

#### Speed

1 km/h = 0.621371 miles/hour

1 m/s = 3.6 km/h

#### Time

1 hour = 60 minutes

1 minute = 60 seconds

1 day = 24 hours

1 year  $\approx 365.25$  days

#### Temperature

°F to °C:

$$T(^{\circ}C) = \frac{5}{9}(T(^{\circ}F) - 32) \tag{1}$$

°C to °F:

$$T(^{\circ}F) = \frac{9}{5}T(^{\circ}C) + 32$$
 (2)

K to °C:

$$T(^{\circ}C) = T(K) - 273.15$$
 (3)

°C to K:

$$T(K) = T(^{\circ}C) + 273.15$$
 (4)

# C Commonly Used Constants

### Gravitational Constant

 $g = 9.81\,\mathrm{m/s^2}$ 

Standard acceleration due to gravity.

### Density of Water

 $\rho_{\text{water}} = 1000 \,\text{kg/m}^3$ At 4°C.

## Density of Air

 $\rho_{\rm air} = 1.225 \, \rm kg/m^3$ 

At sea level and 15°C.

### Young's Modulus for Steel

 $E_{\text{steel}} = 200 \,\text{GPa} = 200 \times 10^9 \,\text{N/m}^2$ Elastic modulus for structural steel.

#### Poisson's Ratio for Steel

 $\nu_{\rm steel} = 0.3$ 

Typical Poisson's ratio for steel.

#### Young's Modulus for Concrete

 $E_{\text{concrete}} = 25 \,\text{GPa} = 25 \times 10^9 \,\text{N/m}^2$ 

Typical elastic modulus for concrete.

#### Poisson's Ratio for Concrete

 $\nu_{\rm concrete} = 0.2$ 

Typical Poisson's ratio for concrete.

#### Boltzmann Constant

 $k = 1.38 \times 10^{-23} \,\mathrm{J/K}$ 

Used in thermodynamics.

#### Gas Constant

 $R = 8.314 \,\mathrm{J/mol \cdot K}$ 

Universal gas constant.

### Speed of Light

 $c = 3 \times 10^8 \,\mathrm{m/s}$ 

Speed of light in a vacuum.

### Atmospheric Pressure

 $P_{\rm atm} = 101.325\,{\rm kPa} = 101325\,{\rm N/m}^2$ 

Standard atmospheric pressure at sea level.

#### Coefficient of Thermal Expansion for Steel

 $\alpha_{\rm steel} = 12 \times 10^{-6} \, \mathrm{K}^{-1}$ 

Thermal expansion coefficient for steel.

# Coefficient of Thermal Expansion for Concrete

 $\alpha_{\rm concrete} = 10 \times 10^{-6} \, \mathrm{K}^{-1}$ 

Thermal expansion coefficient for concrete.

# D Special Trigonometric Relationships

Sine $(\sin \theta)$			
	$\theta$	$\sin \theta$	
		0	
	15°	$\frac{\sqrt{6}-\sqrt{2}}{4}$	
		$\frac{1}{2}$	
	30° 45°	$\frac{\sqrt{2}}{2}$	
	60°	$\frac{\sqrt{3}}{2}$	
		•	

Tangent (tan	$\theta$ )		
	$\theta$	$\tan \theta$	
	0°	0	
	$15^{\circ}$	$2-\sqrt{3}$	
	15° 30° 45° 60°	$\begin{array}{c c} 2 & \sqrt{3} \\ & \frac{1}{\sqrt{3}} \\ & 1 \end{array}$	
	$45^{\circ}$	1	
	$60^{\circ}$	$\sqrt{3}$	
		,	

# Cosine $(\cos \theta)$ $\begin{array}{c|cccc} \theta & \cos \theta \\ \hline 0^{\circ} & 1 \\ 15^{\circ} & \frac{\sqrt{6}+\sqrt{2}}{4} \\ 30^{\circ} & \frac{\sqrt{3}}{2} \\ 45^{\circ} & \frac{\sqrt{2}}{2} \\ 60^{\circ} & \frac{1}{2} \end{array}$

# Trigonometric Identities Pythagorean: $\sin^2\theta + \cos^2\theta = 1$ also: $\sec^2\theta - 1 = \tan^2\theta$ Sine: $\sin(\theta + 180^\circ) = -\sin\theta$ also: $\sin(90^\circ - \theta) = \cos\theta$ Cosine: $\cos(\theta + 180^\circ) = -\cos\theta$ Tangent: $\tan(\theta + 180^\circ) = \tan\theta$