#### CS202: COMPUTER ORGANIZATION

#### **Lecture 4**

**Instruction Set Architecture(2)** 

#### Recap

- Instruction set architecture
  - RISC vs. CISC
  - MIPS/ARM/x86
- Instructions:
  - Arithmetic instruction: add, sub, ...
  - Data transfer instruction: lw, sw, lh, sh, ...
  - Logical instruction: and, or, ...
  - Conditional branch beq, bne, ...
- Basic concepts:
  - Operands: register vs. memory vs. immediate
  - Numeric representation: signed, unsigned, sign extension
  - Instruction format: R-format vs. I-format

# Today's topic

- More control instructions
- Procedure call/return

#### Control Instructions: if else

- Conditional branch: Jump to instruction L1 if register1 equals to register2: beq register1, register2, L1 Similarly, bne and slt (set-on-less-than)
- Unconditional branch:

```
j L1
jr $s0
```

```
Convert to assembly: bne $s3, $s4, Else if (i == j) add $s0, $s1, $s2 f = g+h; j Exit else Else: sub $s0, $s1, $s2 f = g-h; Exit:
```

#### Loop

#### Convert to assembly:

```
while (save[i] == k)
i += 1;
```

i and k are in \$s3 and \$s5 and base of array save[] is in \$s6

```
Loop: sll $t1, $s3, 2
add $t1, $t1, $s6
lw $t0, 0($t1)
bne $t0, $s5, Exit
addi $s3, $s3, 1
j Loop
Exit:
```

#### More Conditional Operations

- How to compile:
  - If (a < b) ..., else, ...</p>
- slt rd, rs, rt
  - if (rs < rt) rd = 1; else rd = 0;</p>
- slti rt, rs, constant
  - if (rs < constant) rt = 1; else rt = 0;</p>
- Use in combination with beq, bne

```
slt $t0, $s1, $s2 # if ($s1 < $s2)
bne $t0, $zero, L # branch to L
```

#### Example

#### Convert to assembly:

```
Convert to assembly:

if (i < j)

f = g+h;

else

f = g-h;
```

```
slt $t0, $s3, $s4
beq $t0, $zero, Else
add $s0, $s1, $s2
j Exit
Else: sub $s0, $s1, $s2
Exit:
```


i and j are in \$s3 and \$s4, f,g and h are in \$s0, \$s1 and \$s2

#### Question

- C has many statements for decisions and loops, while
   MIPS has few. Which of the following do or do not explain this imbalance? Why?
  - A. More decision statements make code easier to read and understand.
  - B. Fewer decision statements simplify the task of the underlying layer that is responsible for execution.
  - C. More decision statements mean fewer lines of code, which generally reduces coding time.
  - D. More decision statements mean fewer lines of code, which generally results in the execution of fewer operations.

#### Pseudo Instructions

- blt \$s0, \$s1, Label
  - If s0<s1, jump to Label</li>
- bgt \$s0, \$s1, Label
  - If s0>s1, jump to Label
- ble \$s0, \$s1, Label
  - If s0<=s1, jump to Label</li>
- beqz \$s0, Label
  - If s0==0, jump to Label
- li \$t0, 5
  - Load immediate, t0 = 5
- Move \$t0, \$s0
  - t0 = s0



There is no such instructions in hardware,

The assembler translates them into a

combination of real instructions

#### **Branch Instruction Design**

- Why not blt, bge, etc?
- Hardware for <, ≥, ... slower than =, ≠</li>
  - Combining with branch involves more work per instruction, requiring a slower clock
  - All instructions penalized!
- beq and bne are the common case
- This is a good design compromise

# Signed vs. Unsigned

- Signed comparison: slt, slti
- Unsigned comparison: sltu, sltui
- Example

  - \$s1 = 0000 0000 0000 0000 0000 0000 0001
  - slt \$t0, \$s0, \$s1 # signed
    - $-1 < +1 \Rightarrow \$t0 = 1$
  - sltu \$t0, \$s0, \$s1 # unsigned
    - $+4,294,967,295 > +1 \Rightarrow $t0 = 0$

The register contains bits without meaning.


Are the bits represents a signed number or unsigned one? See the instruction!

#### **Procedures**

- A procedure or function is one tool used by the programmers to structure programs
  - Benefit: easy to understand, reuse code
- We can think of a procedure like a spy
  - acquires resources → performs task → covers his tracks → returns back with desired result
- When the procedure is executed (when the caller calls the callee), there are six steps
  - parameters (arguments) are placed where the callee can see them
  - control is transferred to the callee
  - acquire storage resources for callee
  - execute the procedure
  - place result value where caller can access it
  - return control to caller

### **Procedure Calling**

```
Caller: callee: int x = 5; int add ( int a, int b) { int z = add (x, y); x = x + 7; return c; }
```



# Registers Used during Procedure Calling

- The registers are used to hold data between the caller and the callee
  - \$a0 \$a3: four argument registers to pass parameters
  - \$v0 \$v1: two value registers to return the values
  - \$ra: one return address register to return to the point of origin in the caller

## Jump and Link

- program counter (PC)
  - A special register maintains the address of the instruction currently being executed
- The procedure call is executed by invoking the jump-and-link (jal) instruction the current PC (actually, PC+4) is saved in the register \$ra and we jump to the procedure's address (the PC is accordingly set to this address)

jal NewProcedureAddress

- Since jal may over-write a relevant value in \$ra, it must be saved somewhere (in memory?) before invoking the jal instruction
- How do we return control back to the caller after completing the callee procedure?


### Registers


The 32 MIPS registers are partitioned as follows:

```
Register 0 : $zero
                      always stores the constant 0
Regs 2-3 : $v0, $v1
                      return values of a procedure
Regs 4-7 : $a0-$a3
                      input arguments to a procedure
Regs 8-15 : $t0-$t7
                     temporaries
Regs 16-23: $s0-$s7
                      variables
Regs 24-25: $t8-$t9
                      more temporaries
Reg 28 : $gp
                     global pointer
Reg 29 : $sp
                      stack pointer
Reg 30 : $fp
                      frame pointer
Reg 31 : $ra
                     return address
```

#### The Stack

The registers for a procedure are volatile, it disappears every time we switch procedures. Therefore, a procedure's values in the registers are backed up in memory on a stack





### Storage Management on a Call/Return

- A new procedure must create space for all its variables on the stack
- Before executing the jal, the caller must save relevant values in \$s0-\$s7, \$a0-\$a3, \$ra, temps into its own stack space
- Arguments are copied into \$a0-\$a3; the jal is executed
- After the callee creates stack space, it updates the value of \$sp
- Once the callee finishes, it copies the return value into \$v0, frees up stack space, and \$sp is incremented
- On return, the caller may bring in its stack values, ra, temps into registers
- The responsibility for copies between stack and registers may fall upon either the caller or the callee

#### Example 1- leaf procedure

```
int leaf_example (int g, int h, int i, int j)
{
    int f;
    f = (g + h) - (i + j);
    return f;
}
```

Save t0,t1,s0

Protect environment

The caller has saved:

g→\$a0,

h<del>→</del>\$a1,

i**→**\$a2,

j**→**\$a3,

return address → \$ra


Procedure body

Restore t0 t1 s0

Return result

leaf\_example: \$sp, \$sp, -12 addi \$t1, 8(\$sp) SW \$t0, 4(\$sp) SW \$s0, 0(\$sp) SW add \$t0, \$a0, \$a1 \$t1, \$a2, \$a3 add \$s0, \$t0, \$t1 sub add \$v0, \$s0, \$zero \$s0, 0(\$sp) lw \$t0, 4(\$sp) lw \$t1, 8(\$sp) lw \$sp, \$sp, 12 addi \$ra jr

## Data in the stack in example 1



To avoid too many memory operations:

\$t0 - \$t9: temporary registers are not preserved by the callee

\$s0 - \$s7: saved registers must be preserved by the callee if used

- Procedures that call other procedures
- For nested call, caller needs to save on the stack:
  - Its return address
  - Any arguments and temporaries needed after the call
- Restore from the stack after the call

```
int fact (int n)
{
    if (n < 1) return (1);
       else return (n * fact(n-1));
}</pre>
```

#### Notes:

The caller saves \$a0 and \$ra in its stack space.

Temps are never saved.

Compare n<1

Return 1

Fact(n-1)


Return n\*fact(n-1)

```
fact:
          $sp, $sp, -8
  addi
          $ra, 4($sp)
  SW
          $a0, 0($sp)
  SW
          $t0, $a0, 1
 slti
          $t0, $zero, L1
  beq
         $v0, $zero, 1
   addi
         $sp, $sp, 8
   addi
          $ra
   ir
          $a0, $a0, -1
  addi
  jal
         fact
         $a0, 0($sp)
  lw
         $ra, 4($sp)
  lw
          $sp, $sp, 8
  addi
          $v0, $a0, $v0
  mul
 <u>ir</u>
          $ra
```




```
fact:
  addi
          $sp, $sp, -8
         $ra, 4($sp)
  SW
         $a0, 0($sp)
  SW
  slti $t0, $a0, 1
  beq $t0, $zero, L1
   addi $v0, $zero, 1
   addi $sp, $sp, 8
         $ra
L1:
  addi
         $a0, $a0, -1
  jal
         fact
  W
         $a0, 0($sp)
         $ra, 4($sp)
  W
  addi
        $sp, $sp, 8
         $v0, $a0, $v0
  mul
  ir
         $ra
```

a0=2




```
fact:
          $sp, $sp, -8
  addi
         $ra, 4($sp)
  SW
         $a0, 0($sp)
  SW
  slti $t0, $a0, 1
  beq $t0, $zero, L1
   addi $v0, $zero, 1
   addi $sp, $sp, 8
         $ra
L1:
  addi
         $a0, $a0, -1
  jal
         fact
  W
         $a0, 0($sp)
         $ra, 4($sp)
  W
  addi
        $sp, $sp, 8
         $v0, $a0, $v0
  mul
  ir
         $ra
```

$$a0=2$$
  $t0=0$ 




```
fact:
          $sp, $sp, -8
  addi
         $ra, 4($sp)
  SW
         $a0, 0($sp)
  SW
  slti $t0, $a0, 1
  beq $t0, $zero, L1
   addi $v0, $zero, 1
   addi $sp, $sp, 8
         $ra
  addi
         $a0, $a0, -1
  jal
         fact
  W
         $a0, 0($sp)
         $ra, 4($sp)
  W
  addi
        $sp, $sp, 8
         $v0, $a0, $v0
  mul
  ir
         $ra
```

$$a0=1$$
  $t0=0$ 






```
fact:
         $sp, $sp, -8
  addi
         $ra, 4($sp)
  SW
         $a0, 0($sp)
  SW
  slti $t0, $a0, 1
  beq $t0, $zero, L1
   addi $v0, $zero, 1
   addi $sp, $sp, 8
         $ra
L1:
  addi
         $a0, $a0, -1
  jal
         fact
L2: lw
        $a0, 0($sp)
         $ra, 4($sp)
  W
        $sp, $sp, 8
  addi
         $v0, $a0, $v0
  mul
  jr
         $ra
```








```
fact:
  addi
         $sp, $sp, -8
         $ra, 4($sp)
  SW
         $a0, 0($sp)
  SW
  slti $t0, $a0, 1
  beq $t0, $zero, L1
   addi $v0, $zero, 1
   addi $sp, $sp, 8
         $ra
L1:
  addi
         $a0, $a0, -1
  jal
         fact
L2: lw
        $a0, 0($sp)
         $ra, 4($sp)
  W
        $sp, $sp, 8
  addi
         $v0, $a0, $v0
  mul
  jr
         $ra
```




```
fact:
         $sp, $sp, -8
  addi
         $ra, 4($sp)
  SW
         $a0, 0($sp)
  SW
  slti $t0, $a0, 1
  beq $t0, $zero, L1
   addi $v0, $zero, 1
   addi $sp, $sp, 8
         $ra
L1:
  addi
         $a0, $a0, -1
  jal
         fact
L2: lw
        $a0, 0($sp)
         $ra, 4($sp)
  W
        $sp, $sp, 8
  addi
         $v0, $a0, $v0
  mul
  jr
         $ra
```








```
fact:
  addi
        $sp, $sp, -8
         $ra, 4($sp)
  SW
         $a0, 0($sp)
  SW
  slti $t0, $a0, 1
  beq $t0, $zero, L1
   addi $v0, $zero, 1
   addi $sp, $sp, 8
         $ra
L1:
  addi
         $a0, $a0, -1
  jal
         fact
L2: lw
        $a0, 0($sp)
         $ra, 4($sp)
  W
        $sp, $sp, 8
  addi
         $v0, $a0, $v0
  mul
  jr
         $ra
```




```
fact:
         $sp, $sp, -8
  addi
         $ra, 4($sp)
  SW
         $a0, 0($sp)
  SW
  slti $t0, $a0, 1
  beq $t0, $zero, L1
   addi $v0, $zero, 1
   addi $sp, $sp, 8
         $ra
L1:
  addi
         $a0, $a0, -1
  jal
         fact
L2: lw
        $a0, 0($sp)
         $ra, 4($sp)
  W
        $sp, $sp, 8
  addi
         $v0, $a0, $v0
  mul
  jr
         $ra
```




high address

low address

```
fact:
         $sp, $sp, -8
  addi
         $ra, 4($sp)
  SW
         $a0, 0($sp)
  SW
  slti $t0, $a0, 1
  beq $t0, $zero, L1
   addi $v0, $zero, 1
   addi $sp, $sp, 8
         $ra
L1:
  addi
         $a0, $a0, -1
  jal
         fact
L2: lw
        $a0, 0($sp)
         $ra, 4($sp)
  W
        $sp, $sp, 8
  addi
         $v0, $a0, $v0
  mul
  jr
         $ra
```



```
fact:
         $sp, $sp, -8
  addi
         $ra, 4($sp)
  SW
         $a0, 0($sp)
  SW
  slti $t0, $a0, 1
  beq $t0, $zero, L1
   addi $v0, $zero, 1
   addi $sp, $sp, 8
         $ra
L1:
  addi
         $a0, $a0, -1
  jal
         fact
L2: lw
        $a0, 0($sp)
         $ra, 4($sp)
  W
        $sp, $sp, 8
  addi
         $v0, $a0, $v0
  mul
  jr
         $ra
```



## **Saving Conventions**

 Caller saved: Temp registers \$t0-\$t9 (the callee won't bother saving these, so save them if you care), \$ra (it's about to get over-written), \$a0-\$a3 (so you can put in new arguments)

 Callee saved: \$s0-\$s7 (these typically contain "valuable" data)


## **Saving Conventions**

 Caller saved: Temp registers \$t0-\$t9 (the callee won't bother saving these, so save them if you care), \$ra (it's about to get over-written), \$a0-\$a3 (so you can put in new arguments)


 Callee saved: \$s0-\$s7 (these typically contain "valuable" data)

### **Memory Layout**

- Text: program code
- Static data: global variables
  - e.g., static variables in C, constant arrays and strings
  - \$gp initialized to address allowing
     ± offsets into this segment
- Dynamic data: heap
  - E.g., malloc in C, new in Java
- Stack: automatic storage



#### Local Data on the Stack



- Local data allocated by callee
  - e.g., C automatic variables
- Procedure frame (activation record)
  - Used by some compilers to manage stack storage