Lab 5. WebCam and System Integration

I. Purpose

The purpose of this lab is to design and implement a remote video viewer using off-the-shelf WebCam, and perform system integration of RoboCam.

II. Problem Statement

Problem 5. WebCam and System integration

Implement *Video functionality*.

Also perform *system integration* of Video and control functionalities.

We start from the simplest and perform step-by-step improvements.

Problem 5A. Test Capture WebCam on Beaglebone.

Test capture image from WebCam with V4L2 (Video for Linux 2) on Beaglebone.

Problem 5B. Learn SDL2 via Tutorials.

Learn SDL 2 (Simple DirectMedia Layer 2) via Tutorials.

Problem 5C. Implement Video functionality.

Implement Video functionality composed of

- Camera on Beaglebone (Capture from WebCam and send video to network) and
- Viewer on PC (Receive video from network and display video to user) using SDL2.

Problem 5D. System Integration.

Perform system integration of Video and control functionalities:

A. Video functionality composed of

- Camera on Beaglebone (Capture from WebCam and send video to network) and
- Viewer on PC (Receive video from network and display video to user).
- B. Control functionality composed of
 - Commander on PC (Get key input from user and send command packet to network) and
 - Controller on Beaglebone (Receive command packet from network and actuate servos and lights on the robot).

For recording photos and videos, Commander on PC sends user command to Viewer, which records photos and videos to storage device.

Data Flow is summarized as follows:

User	PC	Network	Beaglebone	Robot	
Eye ← Storage ←	Viewer ← (Record command)	Video ←	Camera ←	WebCam	
Finger →	Commander ^→	$Command \to$	Controller →	Servos & Lights	

III. Technical Backgrounds

First Week A. Test Capture WebCam on Bone

1. Choosing a Webcam device driver in Linux

["Webcam", https://help.ubuntu.com/community/Webcam]

Webcam support in Linux is mainly provided by the Linux UVC Project's *UVC driver*. This aims to provide a universal driver in the same way that a generic driver handles USB storage devices (memory sticks, hard drives, etc.). However, other drivers also exist that may allow more devices to be used.

When looking to purchase a webcam for use with Ubuntu, you should look for a *UVC compatible camera*. The Linux-UVC project has a good list of UVC compatible webcams as well as The Quickcam Team for Logitech cameras.

2. UVC compatible cameras

["Linux UVC (USB Video Class) driver and tools", http://www.ideasonboard.org/uvc/]

Welcome to the USB Video Class Linux device driver home.

The goal of this project is to provide all necessary software components to fully support UVC compliant devices in Linux. This include a V4L2 kernel device driver and patches for user-space tools.

The *USB Device Class Definition for Video Devices*, or USB Video Class, defines video streaming functionality on the Universal Serial Bus. Much like nearly all mass storage devices (USB flash disks, external SATA disk enclosures, ...) can be managed by a single driver because they conform to the USB Mass Storage specification, UVC compliant peripherals only need a generic driver.

The UVC specification covers webcams, digital camcorders, analog video converters, analog and digital television tuners, and still-image cameras that support video streaming for both video input and output.

Supported devices

Device ID	Name	Manufacturer	Status
046d:0994	Logitech Quickcam Orbit/Sphere AF	Logitech	
046d:0805	Logitech Webcam C300	Logitech	
046d:0819	Logitech Webcam C210	Logitech	

Can't find Webcam C110, but we proceed.

3. Linux WebCam device drivers and applications

Device driver:

Uvcvideo.ko in kernel

Application programs [For graphic user interface only: Not for Beaglebone, but for PC]: VLC media player, Mplayer, streamer, etc.



4. Video for Linux

["Beaglebone Images, Video and OpenCV", http://derekmolloy.ie/beaglebone-images-video-and-opencv/]

Using v4l2 (Video for Linux version 2), you can capture images. Video4Linux or V4L is a video capture application programming interface for Linux, supporting many USB webcams, TV tuners, and other devices. Video4Linux is closely integrated with the Linux kernel.

What is V4L2?

Video4Linux

https://en.wikipedia.org/wiki/Video4Linux

Video4Linux or **V4L** is a video capture[1] and output device API and driver framework for the Linux kernel, supporting many USB webcams, TV tuners, and other devices. Video4Linux is closely integrated with the Linux kernel. Video4Linux was named after Video for Windows (which is sometimes abbreviated "V4W"), but is not technically related to it.[2][3]

Version 1

V4L had been introduced late into the 2.1.X development cycle of the Linux kernel. V4L1 support was dropped in kernel 2.6.38.

Version 2

V4L2 is the second version of V4L. Video4Linux2 fixed some design bugs and started appearing in the 2.5.X kernels. Video4Linux2 drivers include a compatibility mode for Video4Linux1 applications, though the support can be incomplete and it is recommended to use Video4Linux1 devices in V4L2 mode. The project DVB-Wiki is now hosted on LinuxTV web site.

Software supporting Video4Linux

Ffmpeg, Gstreamer, Motion, Mplayer, OpenCV, Skype, VLC media player, etc.

V4L2 Usage

Getting help

v412-ctl --help

Show driver info

-D, --info show driver info [VIDIOC_QUERYCAP]

v412-ct1 -D

Video capture info

v4l2-ctl --help-vidcap

List supported video formats

v4l2-ctl --list-formats

Type : Video Capture

Pixel Format: 'YUYV'

Name : YUV 4:2:2 (YUYV)

Index : 1

Type : Video Capture

Pixel Format: 'MJPG' (compressed)

Name : MJPEG

Notice that C110 supports two formats: YUYV and MJPG.

Check current video format

v412-ct1 -V

Set video format

-v, --set-fmt-video=width=<w>,height=<h>,pixelformat=<f>

set the video capture format [VIDIOC_S_FMT] pixelformat is either the format index as reported by

--list-formats, or the fourcc value as a string

To YUYV: (Note: Two '-' before set-fmt-video)

v412-ctl --set-fmt-video=width=640,height=480,pixelformat=0

To MJPG:

v4l2-ctl --set-fmt-video=width=640, height=480, pixelformat=1

5. What is YUYV?

["YUYV Format", http://linuxtv.org/downloads/v4l-dvb-apis/V4L2-PIX-FMT-YUYV.html]

Name

V4L2_PIX_FMT_YUYV — Packed format with ½ horizontal chroma resolution, also known as YUV 4:2:2

Description

In this format each four bytes is two pixels. Each four bytes is two Y's, a Cb and a Cr. Each Y goes to one of the pixels, and the Cb and Cr belong to both pixels. As you can see, the Cr and Cb components have half the horizontal resolution of the Y component. V4L2_PIX_FMT_YUYV is known in the Windows environment as

YUY2.

Y'UV422 can also be expressed in YUY2 FourCC format code. That means 2 pixels will be defined in each macropixel (four bytes) treated in the image. [5]

Y0 U0 Y1 V0 Y2 U1 Y3 V1 ...




Fig. 5.1 YUYV format

6. What is JPEG?

https://en.wikipedia.org/wiki/JPEG

JPEG (/ˈdʒeɪpɛg/ JAY-peg)^[1] is a commonly used method of lossy compression for digital images, particularly for those images produced by digital photography. The degree of compression can be adjusted, allowing a selectable tradeoff between storage size and image quality. JPEG typically achieves 10:1 compression with little perceptible loss in image quality. [2]

JPEG compression is used in a number of image file formats. JPEG/Exif is the most common image format used by digital cameras and other photographic image capture devices; along with JPEG/JFIF, it is the most common format for storing and transmitting photographic images on the World Wide Web. [3] These format variations are often not distinguished, and are simply called JPEG.

The term "JPEG" is an acronym for the <u>Joint Photographic Experts Group</u>, which created the standard. The <u>MIME media type</u> for JPEG is *image/jpeg*, except in older Internet Explorer versions, which provides a MIME type of *image/pjpeg* when uploading JPEG images. [4] JPEG files usually have a filename extension of *.jpg* or *.jpeg*.

Checking Jpeg image can be donw with the following function:

```
// Check_Jpeg(image): Check SOI/EOI and Returns 1 if Jpeg image, 0 otherwise.
int Check_Jpeg(unsigned char *image, int size)
{
    // Check SOI 0xffd8 at the head of Jpeg image
    // Also Check EOI 0xffd9 at the end of Jpeg image
    if (image[0] == 0xff && image[1] == 0xd8
        && image[size-2] == 0xff && image[size-1] == 0xd9 ) return 1;
    else return 0;
}
```

7. What is MJPG?

https://en.wikipedia.org/wiki/Motion JPEG

In multimedia, **Motion JPEG** (**M-JPEG** or **MJPEG**) is a video compression format in which each video frame or interlaced field of a digital video sequence is compressed separately as a <u>JPEG image</u>. Originally developed

for multimedia PC applications, M-JPEG is now used by video-capture devices such as digital cameras, IP cameras, and webcams; and by non-linear video editing systems. It is natively supported by the QuickTime Player, the PlayStation console, and web browsers such as Safari, Google Chrome, Mozilla Firefox and Microsoft Edge.

8. Image capture program

Capture.c

The source video capture code is from:

file: media/v4l/capture.c

https://www.linuxtv.org/downloads/v4l-dvb-apis-new/uapi/v4l/capture.c.html

Download to a_CaptureBone/Capture_LinuxTV.c.

This is a generic example program to capture from WebCam using V4L2.

Use this program to capture images with some modifications.

B. Learn SDL via Tutorials.

9. Simple DirectMedia Layer

https://en.wikipedia.org/wiki/Simple DirectMedia Layer

Simple DirectMedia Layer (**SDL**) is a cross-platform software development library designed to provide a low level hardware abstraction layer to computer multimedia hardware components. Software developers can use it to write high-performance computer games and other multimedia applications that can run on many operating systems such as Android, iOS, Linux, Mac OS X, Windows and other platforms.

SDL manages <u>video</u>, audio, input devices, CD-ROM, threads, shared object loading, networking and timers. For 3D graphics it can handle an OpenGL or Direct3D context.

The library is internally written in \underline{C} and Objective-C and provides the application programming interface in \underline{C} , with bindings to other languages available. It is free and open-source software subject to the requirements of the zlib License since version 2.0 and with prior versions subject to the GNU Lesser General Public License. Under the zlib License, SDL 2.0 is freely available for static linking in closed-source projects, unlike SDL 1.2.

SDL is extensively used in the industry in both large and small projects. Over 700 games, 180 applications, and 120 demos have also been posted on the library website.

A common misconception is that SDL is a game engine, but this is not true. However, the library is well-suited for building an engine on top of it.




Fig 5.2 Abstraction layers of several SDL platforms

SDL is divided into several subsystems:[

Video

Display and Window Management, surface functions, rendering acceleration, etc. Input Events

Event handling, Support for Keyboard, Mouse, Joystick and Game controller

Threads

multi-threading: Thread Management, Thread Synchronization Primitives, Atomic Operations

There also are a few separate official libraries that provide some more functions. These comprise the "standard library", and are provided on the official website and included in the official documentation:

10. SDL_image — support for multiple image formats

*IMAGE in SDL: Lesson 06. Extension Libraries and Loading Other Image Formats*http://lazyfoo.net/tutorials/SDL/06 extension_libraries_and_loading_other_image_formats/index.php

SDL extension libraries allow you do things like load image files besides BMP, render TTF fonts, and play music. You can set up SDL_image to load PNG files, which can save you a lot of disk space. In this tutorial we'll be covering how to install SDL_image.

IMG_LoadJPG_RW

SDL_Surface ***IMG_LoadJPG_RW**(SDL_RWops **src*)

STC

The source SDL_RWops as a pointer. The JPG image is loaded from this.

Load *src* as a JPG image for use as a surface, if JPG support is compiled into the SDL_image library. **Note**: If the image format loader requires initialization, it will attempt to do that the first time it is needed if you have not already called IMG_Init to load support for your image format.

Returns: a pointer to the image as a new SDL_Surface. **NULL** is returned on errors, like if JPG is not supported, or a read error.

```
// load sample.jpg into image
SDL_Surface *image;
SDL_RWops *rwop;
rwop=SDL_RWFromFile("sample.jpg", "rb");
image=IMG_LoadJPG_RW(rwop);
if (!image) {
    printf("IMG_LoadJPG_RW: %s\n", IMG_GetError());
    // handle error
}
```

Checked that SDL can load PNG and Jpeg images.

11. SDL Event Handling

SDL event handling system [Lesson 3]

```
Input (SDL_Eevent) Event queue Check
Press key SDL_KeyboardEvent
SDL_PollEvent
Move mouse SDL_MouseMotionEvent
Joystick SDL_JoyButtonEvent
Touch a touch screen
```

1) SDL_Event (union)

A SDL event is something like a key press, mouse motion, joy button press, etc.

```
SDL_Event
Uint32
SDL_Common/Window/QuitEvent
SDL_KeyboardEvent
SDL_MouseMotion/Button/WheelEvent
SDL_JoyAxis/Ball/Hat/Button/DeviceEvent
```

Event queue

The event queue will then store them in the order the events occured waiting for you to process them.

SDL_PollEvent

When you want to find out what events occured so you can process them, you poll the event queue to get the most recent event by calling SDL_PollEvent. What SDL_PollEvent does is take the most recent event from the event queue and puts the data from the event into the SDL_Event we passed into the function.

SDL_PollEvent will keep taking events off the queue until it is empty. When the queue is empty, SDL_PollEvent

will return 0. So what this piece of code does is keep polling events off the event queue until it's empty. If an event from the event queue is an SDL_QUIT event (which is the event when the user Xs out the window), we set the quit flag to true so we can exit the application.

```
//Handle events on queue
while ( SDL_PollEvent( &e ) != 0 ) {
    //User requests quit
    if ( e.type == SDL_QUIT ) {
        quit = true;
    }
}
```

2) SDL_KeyboardEvent [Lesson4]

https://wiki.libsdl.org/SDL_KeyboardEvent

Inside of the SDL Event is an SDL Keyboard event which contains the information for the key event.

Data Fields

Uint32	type	the event type; SDL_KEYDOWN or SDL_KEYUP
Uint32	timestamp	timestamp of the event
Uint32	${\bf window ID}$	the window with keyboard focus, if any
Uint8	state	the state of the key; SDL_PRESSED or SDL_RELEASED
Uint8	repeat	non-zero if this is a key repeat
SDL Kevsvm	kevsvm	the SDL Keysym representing the key that was pressed or released

3) SDL_Keysym

Inside of SDL_KeyboardEvent is a SDL Keysym which contains the information about the key that was pressed. That Keysym contains the SDL Keycode which identifies the key that was pressed.

Data Fields

```
SDL_Scancode scancode SDL physical key code; see SDL_Scancode for details SDL_Keycode sym SDL virtual key code; see SDL_Keycode for details Uint16 mod current key modifiers; see SDL_Keymod for details Uint32 unused
```

SDL_Scancode & SDL_Keycode are defined for each key. Keymod: None, L/Rshift, L/Rctrl, L/Ralt, ...

4) SDL_Keycode

```
SDL_Event = SDL_KeyboardEvent > SDL_Keysym > SDL_Keycode window/time/up or down ScanCode/Keycode/Keymod
```

SDL_Keycode Value

```
SDLK_0-9, a-z, F1-24,
SDLK_UP/DOWM/LEFT/RIGHT (Four arrow keys)

SDL Events Summary
```

SDL_Event

Uint32

SDL_Common/Window/QuitEvent

SDL_KeyboardEvent

SDL_MouseMotion/Button/WheelEvent

SDL_JoyAxis/Ball/Hat/Button/DeviceEvent

.....

SDL_KeyboardEvent

```
https://wiki.libsdl.org/SDL_KeyboardEvent

Uint32 type // SDL_KEYDOWN, SDL_KEYUP

Uint32 timestamp
```

Uint32windowID// The window with keyboard focusUint8state// SDL_PRESSED, SDL_RELEASED.Uint8repeat// Nonzero of this is a key repeat

SDL_Keysym keysym // The key that was pressed/released

https://wiki.libsdl.org/SDL_Keysym

SDL_Scancode scancode // SDL_SCANCODE_0-9/A-Z/a-z

SDL_Keycode sym // SDLK_0-9/A-Z/a-z

Uint16 mod // SDL_Keymod

https://wiki.libsdl.org/SDL_Keymod // KMOD_L/R SHIFT/CTRL/ALT etc.

Uint32 unused

Struct SDL_keysym

https://www.libsdl.org/release/SDL-1.2.15/docs/html/guideinputkeyboard.html

```
typedef struct{
  Uint8 scancode;
  SDLKey sym;
  SDLMod mod;
  Uint16 unicode;
} SDL_keysym;
```

C. Implement Video functionality.

See V. Design.

D. System Integration

See V. Design.

IV. Equipment and Parts

1. Lab equipment

Router

IBM PC with Windows and Linux (Dual boot)
Embedded board Beaglebone with cables and 4GB SD

2. Electronic parts

ID	Part No	Description	Qty/ group	Unit price
51	C110	Logitech WebCam	1	16,860
52	XH 400	Unicon 4-port USB Hub or equivalent	1	4,300

Note. In order to test with batteries, you need to charge batteries fully beforehand, using LiPo charger and NiMH charger.

V. Design

Pre-report for first week

- 1. Search internet for C110 specifications. You can visit www.logitech.com..
- 2. Design SDL program for Key Values (Problem 5B)
- a. Design Get_Key_Var_SDL.cpp

Objective

Prints SDL_Scancode, SDL_Keycode, and SDL_Keymod (in hexadecimal) for each key pressed. Find which data is useful.

Algorithm

```
1. init()

SDL_Init()

SDL_CreateWindow()

SDL_GetWindowSurface() // Get window surface
3. Event loop in main()

A. SDL_PollEvent()

Print Key Vars
9. close()
```

```
SDL_DestroyWindow()
SDL_Quit()
```

Edit

Find which variable is useful for key input: SDL Scancode, SDL Keycode, and SDL Keymod.

b. Design Key_Value_SDL.cpp

Objective

Keycode is the same as ASCII value?

Get key input without Enter key (similar to raw key input) for left 4x3 keys:

Coding

May Use symbols for Keycode afterwards.

https://wiki.libsdl.org/SDL Keycode

```
Print keycode value as %02xh and %c & fflush(stdout)!
    kcode = e.key.keysym.sym;

printf("%02xh '%c'; ", kcode, kcode);
    fflush(stdout);
```

Pre-report for second week

3. Design Video functionality (Problem 5C).

Video functionality is composed of

- Camera on Beaglebone (Capture from WebCam and send video to network) and
- Viewer on PC (Receive video from network and display video to user) using SDL2.

Data flow in detail

<u>User</u>	PC	Network	Beaglebone	Robot
SW:	<u>Viewer</u>		<u>Camera</u>	
			Capture images ←	← WebCam
			←Send Jpeg images	
		←UDP packets		
	Recv Jpeg images ←			
See video	←Display video SDL			

Camera.c on Bone

Use X.c for cross-gcc compatibility!

Modify Capture2.c to add UDP send functionality

Additional file: Send_UDP.c for UDP-related routines.

Jpeg format: Use 320x240 Jpeg images!

Video stream packet

Sequence of Jpeg images (Mjpg video from WebCam) Variable size.

Viewer.cpp using SDL2 on PC

Main loop used for polling events. Require a thread to listen from socket and display.

Additional file: Recv_UDP.cpp for UDP-related routines.

Algorithm for Camera.c on Bone

- 0. Get argument of Capture: CPORT (4960) to send Including -p for ports & -a for ip_addr.
- 1. Init UDP packet
- 5. Loop

Capture Webcam to Jpeg image Sendto Jpeg image to UDP datagram

9. Close UDP packet

Algorithm for Viewer.c on PC (using SDL2)

Main

- 1. init() // Init SDL2
- 2. Fill the surface with light grey & update the surface
- 3. Init UDP port with any IP and CPORT (4960) to listen
- 4. Run a thread RecvDispThread to listen to datagram and display Jpeg image
- 5. Key event loop

Just print input key value.

RecvDispThread

Loop

- A. recvfrom() socket datagram print the number of received bytes
- B. Check if Jpeg image (Header & Trailer)
- C. Display Jpeg image using SDL2

Note. Two programs (one on PC, another on Bone) are going to be tested with simultaneous operation. Bugs may exist on both programs, which make debugging difficult.

One good method is debug program on Bone first (capture and send) with a small program on PC with receive only (without viewer with SDL): Modified from listener.c to simply check and print received packet size.

4. Design for System Integration (Problem 5D)

Allocate multi-tasking with thread

HW	PC	Beaglebone	
SW: tasks	Viewer: Thread Receive video from network and display video to user (SDL2). Viewer, which records photos and videos to storage device.	Camera: Task Capture from WebCam and send video to network.	
	Commander: Task Get key input from user and send command packet to network (SDL2). For recording photos and videos, Commander on PC sends user command to Viewer.	actuate servos and lights on the robot.	

Why two tasks on Beaglebone?

Since two tasks of Camera and Controller are independent.

How to run two tasks on Beaglebone?

Use two terminals for Bone: One with minicom, and the orher using ssh.

Using two terminals, outputs of each program is not inter-mixed.

Why Thread for Viewer?

Since Viewer requires user key input (photo and video), it should be inside the same memory space. Hence we use Task for Commander, Thread for Viewer, in order to share variables. Note that both commander/viewer can be controlled by a single key input process inside SDL.

Directory

e_SystemI-Integration

Subdirectory to store photos and videos

Photo

Video

Files in Directory

Camera on Beaglebone

Camera.c, Send_UDP.c

Commander/Viewer using SDL2 on PC

Viewer.cpp (containing Viewer thread), Recv_UDP.cpp, Commander.cpp, Send_Cmd.cpp.

Controller on Beaglebone

Control_TMR.c, Recv_Cmd.c, gpio_control.c, gpio_control.h, Init_PWMSS.sh, Acquire_Triple_PWMs.sh, Release-Triple_PWMs.sh

Makefile

Dataflow with multi-task in detail

User PC Bone Robot

← See with WebCam

Camera task

Capture WebCam \leftarrow

← Ssend img datagrams

Viewer thread

Recv img datagrams ← ← Display with SDL2. Record photo/video.

Watches display ←
Issue key commands →
(Servos, Lights, Photo, and Video)

Commander task

Get user key command in raw mode with SDL2

Classify internal/external command

Handle internal command (Photo & Video) to Viewer ^

Send external command to cmd datagram →

Control task

 \rightarrow Recv cmd datagram Control Servos and lights \rightarrow

Move and illuminate

Network packets

Image packet

Single Jpeg image, variable size.

Command packet

ASCII string composed of Id, ti,=me, vx, vy, wr, RL, and LL.

Algorithm

Camera on Bone & Viewer thread are the same as Video functionality in Problem 5C.

Commander task is essentially the same as Keyboard_Commander_PC in Lab 4. Control task is the same as WiFi_Control_TMR in Lab 4.

You need to add

Catch 'p' photo and 'v' video keys from user (without Enter).

It should be transferred to Viewer thread.

In the viewer thread, record to a file in either Photo or Video directory, with filename "photoNNN.jpg" or "videoNNN.mjpg", where NNN can range from 000 to 999 to store up to 1000 files. After storing file photo999.jpg, the next photo will be over-written to photo000.jpg. Using this scheme, error of "hard disk full" can be avoided..

VI. Lab Procedures

First Week A. Capture WebCam on Bone

Test capture image from WebCam with V4L2 (Video for Linux 2) on Beaglebone.

11. Check for WebCam device and UVC device driver

First issue "Isusb" with connecting WebCam C110 to Bone via USB hub.

```
$ lsusb
Bus 001 Device 004: ID 046d:0829 Logitech, Inc.
```

Device with ID 046d:0829 is detected, but cannot identify its name.

Check with "dmesg":

```
$ dmesg | grep Webcam
[    1.823628] usb 1-1.2: Product: Webcam C110
[    13.838397] uvcvideo: Found UVC 1.00 device Webcam C110 (046d:0829)
[    14.029731] input: Webcam C110 as /devices/ocp.3/47400000.usb/musb-hdrc.1.aut
o/usb1/1-1/1-1.2/1-1.2:1.0/input/input1
```

Logitech WebCam C110 is detected by Linux!

Check UVC device driver.

<u>Linux 2.6.26 and newer includes the Linux UVC driver natively</u>. You will not need to download the driver sources manually unless you want to test a newer version or help with development.

```
# lsmod | grep uvc
uvcvideo 57013 0
videobuf2 vmalloc 2490 1 uvcvideo
```

uvcvideo device driver module is already installed.

When you do "Is /dev", you should see video0 at the bottom:

```
# ls /dev
/dev/audio1
....
/dev/video0
```

.....

12. Install Video4Linux2 and Test

Refer Image Capture with WebCam on Bone

"Beaglebone Images, Video and OpenCV", http://derekmolloy.ie/beaglebone-images-video-and-opencv/

Video4Linux or V4L is a video capture application programming interface for Linux, supporting many USB webcams, TV tuners, and other devices. Video4Linux is closely integrated with the Linux kernel.

Install v4l2 on Bone

```
# sudo apt-get install v4l-utils
# sudo apt-get install libv4l-dev
```

To list the devices:

```
# v4l2-ctl --list-devices
Webcam C110 (usb-musb-hdrc.1.auto-1.2):
/dev/video0
```

To list the formats available:

Notice that C110 supports output format

YUYV MJPG

Get the driver detail:

```
Driver version: 3.8.13
Capabilities : 0x8400001
Video Capture
Streaming
Device Capabilities
Device Caps : 0x04000001
Video Capture
Streaming
```

We can list the controls available:

```
# v4l2-ctl -L
                      brightness (int)
                                        : min=-64 max=64 step=1 default=0 value=0
                       contrast (int)
                                        : min=0 max=30 step=1 default=13 value=13
                                        : min=0 max=127 step=1 default=38 value=38
                      saturation (int)
                                         : min=-16000 max=16000 step=1 default=0 value=0
                            hue (int)
                                        : default=1 value=1
white_balance_temperature_auto (bool)
                                          : min=20 max=250 step=1 default=100 value=100
                           gamma (int)
                                         : min=0 max=2 default=1 value=1
           power_line_frequency (menu)
                                    0: Disabled
                                    1: 50 Hz
                                     2: 60 Hz
      white_balance_temperature (int)
                                        : min=2800 max=6500 step=1 default=5000 value=5000 flags=inactive
                      sharpness (int)
                                        : min=0 max=100 step=1 default=35 value=35
                                        : min=0 max=1 step=1 default=0 value=0
         backlight_compensation (int)
                  exposure_auto (menu)
                                          : min=0 max=3 default=3 value=3
                                    1: Manual Mode
                                     3: Aperture Priority Mode
              exposure_absolute (int)
                                         min=2 max=5000 step=1 default=312 value=312 flags=inactive
         exposure auto priority (bool)
                                       : default=0 value=1
                                        : min=-72000 max=72000 step=3600 default=0 value=0
                   pan_absolute (int)
                  tilt_absolute (int)
                                      : min=-54000 max=54000 step=3600 default=0 value=0
                                         : min=1 max=2 step=1 default=1 value=1
                  zoom_absolute (int)
```

Get all of the information available for the camera:

```
# v4l2-ctl --all
Driver Info (not using libv4l2):
       Driver name : uvcvideo
       Card type
                    : Webcam C110
       Bus info
                     : usb-musb-hdrc.1.auto-1.1
       Driver version: 3.8.13
       Capabilities : 0x84000001
              Video Capture
              Streaming
              Device Capabilities
       Device Caps
                    : 0x04000001
              Video Capture
              Streaming
Priority: 2
Video input : 0 (Camera 1: ok)
Format Video Capture:
       Width/Height : 640/480
       Pixel Format : 'YUYV'
       Field
                    : None
       Bytes per Line: 1280
       Size Image
                     : 614400
```

```
Colorspace
                    : SRGB
Crop Capability Video Capture:
                  : Left 0, Top 0, Width 640, Height 480
       Bounds
       Default
                  : Left 0, Top 0, Width 640, Height 480
       Pixel Aspect: 1/1
Streaming Parameters Video Capture:
       Capabilities
                       : timeperframe
       Frames per second: 30.000 (30/1)
       Read buffers
                       : 0
                                      : min=-64 max=64 step=1 default=0 value=0
                  brightness (int)
                    contrast (int)
                                      : min=0 max=30 step=1 default=13 value=13
                  saturation (int)
                                     : min=0 max=127 step=1 default=38 value=38
                                   : min=-16000 max=16000 step=1 default=0 value=0
                         hue (int)
white_balance_temperature_auto (bool)
                                       : default=1 value=1
                       gamma (int)
                                    : min=20 max=250 step=1 default=100 value=100
         power_line_frequency (menu) : min=0 max=2 default=1 value=1
     white_balance_temperature (int)
                                      : min=2800 max=6500 step=1 default=5000
value=5000 flags=inactive
                   sharpness (int)
                                      : min=0 max=100 step=1 default=35 value=35
                                      : min=0 max=1 step=1 default=0 value=0
        backlight compensation (int)
                exposure_auto (menu) : min=0 max=3 default=3 value=3
            exposure_absolute (int) : min=2 max=5000 step=1 default=312 value=312
flags=inactive
        exposure auto priority (bool) : default=0 value=1
                 pan_absolute (int)
                                      : min=-72000 max=72000 step=3600 default=0
value=0
                tilt absolute (int) : min=-54000 max=54000 step=3600 default=0
value=0
                zoom_absolute (int)
                                     : min=1 max=2 step=1 default=1 value=1
```

13. Control with v4l2

We can then set an individual value. For example to set the brightness:

If we wish to modify the resolution:

```
# v4l2-ctl --set-fmt-video=width=640,height=480,pixelformat=1
```

Pixelformat: as shown in "v4l2-ctl -list-formats"

0: YUYV 1: MJPG

Check current format

```
# v4l2-ctl -V
```

```
Format Video Capture:
Width/Height: 640/480
Pixel Format: 'MJPG'
Field: None
Bytes per Line: 0
Size Image: 921600
Colorspace: SRGB
Custom Info: feedcafe
```

14. Get capture.c program

The source video capture code is from:

file: media/v4l/capture.c

https://www.linuxtv.org/downloads/v4l-dvb-apis-new/uapi/v4l/capture.c.html

Download to a_CaptureBone/Capture_LinuxTV.c.

This is a generic example program to capture from WebCam using V4L2.

Copy this file to Capture2.c (to be modified).

15. Edit and cross-compile on PC

The original program captures 'frame_count' images, which is preset as 70.

Change mainloop() as

In the program, search for printf statements. Many ""\wn"'s are not correct. Change "\wwn" or "n" to "\wn"...

Edit makefile to include:

Capture2: Capture2.c

Arm-linux-gnueabhif-gcc -g -o Capture2 Capture2.c

Build

\$ make

16. Test Capture 2 on Bone as root

a. See help message:

```
# ./Capture2 --help
Usage: ./Capture2 [options]
Version 1.3
Options:
-d | --device name  Video device name [/dev/video0]
-h | --help
                   Print this message
-m | --mmap
                   Use memory mapped buffers [default]
-r | --read
                   Use read() calls
-u | --userp
                   Use application allocated buffers
-o | --output
                   Outputs stream to stdout
-f | --format
                    Force format to 640x480 YUYV
-c | --count
                    Number of frames to grab [70]
```

Notice that the number of frames to grab is preset to "70": This is why we added infinite number of captures for video.

b. Capture YUYV as root

```
Run Capture2 to get a 640x480 YUYV image on Bone
# v412-ctl --set-fmt-video=width=640,height=480,pixelformat=0
# ./Capture2 -c 1 -o > cap640a.yuv
select timeout

# 1s -la cap*
-rw-r--r- 1 root root 0 Feb 10 02:29 cap640a.yuv
```

It seems that 640x480 YUYV is too heavy to capture on Bone.

File size?

```
It contains 320x240 YUYV image data (2 bytes per pixel): 240 rows * 320 columns * 2 bytes = 153,600 bytes.
```

One more capture 320x240 YUYV image on Bone

Notice that the file size of YUYV image is always a constant, depending on resolution.

See raw image? Can't.

You can see the raw data with hd (Hexadecimal dump):

Notice that four-byte patterns are repeated.

c. Capture JPEG and see

```
Run Capture2 to get a 640x480 jpeg image on Bone
# v412-ctl --set-fmt-video=width=640,height=480,pixelformat=1
# ./Capture2 -c 1 -o > cap640a.jpg
```

```
.
# ls -la cap*.jpg
-rw-r--r-- 1 root root 6948 Feb 10 02:46 cap640a.jpg
```

Cannot see the image by clicking the file in File browser on PC... Seems that it is an invalid file.

Try mjpeg first!

```
# ./Capture2 -c 100 -o > cap640a.mjpg
```

```
# ls -la cap*.mjpg
-rw-r--r-- 1 root root 6331668 Feb 10 02:49 cap640a.mjpg
```

Can see the mjpg video by clicking the file in File browser on PC!

Run Capture2 again to get a 640x480 jpeg image on Bone

Can see cap640b.jpg image by clicking the file in File browser on PC!

Notice that JPEG file size is variable even for the same resolution: Dependent on image complexity.

Question. Why capture Jpeg correctly only after capture mjpg?

d. Capture (record) MJPG video and see

Note. Fresh start: Disconnect and reconnect USB connector of WebCam.

Capture video 10 s twice.

```
# v412-ctl --set-fmt-video=width=640,height=480,pixelformat=1
# ./Capture2 -c 300 -o > cap640b.mjpg
# ./Capture2 -c 300 -o > cap640c.mjpg
```

Check file size

```
$ 1s -la cap*.mjpg
-rw-r--r-- 1 root root 15629532 2월 10 12:07 cap640b.mjpg
-rw-r--r-- 1 root root 19904596 2월 10 12:08 cap640c.mjpg
capture2_bone_2.mjpg is 5,027,696 bytes or similar.
```

Can you see a MJpeg image?

Double click mjpg image cap640c.mjpg shows still image only! Double click mjpg image cap640b.mjpg opens Gedit: Cancel it!! Try this on PC:

```
$ sudo apt-get install mplayer
$ mplayer cap640c.mjpg
```

Can you see a video?

B. Learn SDL via Tutorial

20. Install SDL on PC

Refer: Install - Setting up SDL 2 on Linux

http://lazyfoo.net/tutorials/SDL/01 hello SDL/linux/index.php

21. Create SDL2 window

Refer

Setting Up SDL2 on g++

http://lazyfoo.net/tutorials/SDL/01 hello SDL/linux/cli/index.php

Hello SDL: Your First Graphics Window

http://lazyfoo.net/tutorials/SDL/01 hello SDL/index2.php

Algorithm

```
1. Define SDL_Window
```

- 2. Define SDL_Surface
- 3. SDL Init()
- 3.1 SDL_CreateWindow() // Actually Step 4.
- 3.2 SDL_GetWindowSurface() // Get window surface
- 3.3 SDL FillRect() // Fill window with specified RGB color
- 3.4 SDL_UpdateWindowSurface()
- 3.5 SDL_Delay()
- 8. SDL_DestroyWindow()
- 9. SDL_Quit()

View what kind of SDL functions are used.

Compile

```
$ g++ 01_hello_SDL.cpp -w -lSDL2 -o 01_hello_SDL
```

22. View a BMP image on screen

Refer: Tutorial 02 - Lesson 2. Getting an Image on the Screen http://lazyfoo.net/tutorials/SDL/02 getting an image on the screen/index.php

Algorithm

```
    init()
        SDL_Init()
        SDL_CreateWindow()
        SDL_GetWindowSurface() // Get window surface
        loadMedia()
        SDL_LoadBMP() // hello_world.bmp image file is loaded to a buffer.

        SDL_BlitSurface() // Apply the image
        SDL_UpdateWindowSurface()
```

```
5. SDL_Delay() // 2s9. close()SDL_FreeSurface()SDL_DestroyWindow()
```

23. Event driven programming

SDL_Quit()

Here we'll start handling user input by allow the user to X out the window.

Refer Tutorial 03 – Lesson 03. Event Driven Programming http://lazyfoo.net/tutorials/SDL/03 event driven programming/index.php

24. Key press

Here we'll learn to handle keyboard input.

Refer: Tutorial 04 – Lesson 04. Key Presses http://lazyfoo.net/tutorials/SDL/04 key presses/index.php

25. Image stretching

Now that we know how to load and blit surfaces, it's time to make our blits faster. We'll also take a smaller image and stretch it to fit the screen.

Refer: Tutorial 05 - Lesson 05. Optimized Surface Loading and Soft Stretching http://lazyfoo.net/tutorials/SDL/05 optimized surface loading and soft stretching/index.php

26. Load PNG and Jpeg image

Here we'll be using the SDL image extension library to load png images.

Refer: Tutorial 06 - Lesson 06. Extension Libraries and Loading Other Image Formats http://lazyfoo.net/tutorials/SDL/06 extension_libraries_and_loading_other_image_formats/index.php

Install

\$ sudo apt-get install libsdl2-image-dev

Includes

Now you may get an error saying it can't find SDL_image.h. For linux, we'll have to include the SDL headers like this:

```
#include<SDL2/SDL_image.h>
For SDL_ttf and SDL_mixer, we have to include them like this:
    #include<SDL2/SDL_ttf.h>
    #include<SDL2/SDL_mixer.h>
```

Change this program to load Jpeg image.
Test with a 320x240 captured Jpeg image, and view stretched image.
You can use v4l2-ctl to change the image size, and then capture a Jpeg image.
Can you see the captured Jpeg image?

27. Thread

Multithreading allows your program to do things simultaneously. Here we'll make things print to the console from outside our main thread.

Refer Lesson 46. Multithreading http://lazyfoo.net/tutorials/SDL/46 multithreading/index.php

This thread will be used to implement Viewer on PC.

28. Test Get_Key_Var_SDL.

Test prepared program.

29. Test Key_Value_SDL.

Test prepared program.

These key values will be used in Problem 5C.

C. Test Video Functionality

31. Make a working directory

```
Use a suitable direcory name, e.g.,

# mkdir -p 5 WebCam SI/c VideoFunctionality
```

32. Edit source files

Edit the following source files

Camera on Bone Camera.c Send_UDP.c

Viewer using SDL2 on PC Viewer.cpp Recv_UDP.cpp

Note that we use SDL2 in Viewer, which should be compiled with g++. Hence we name source files as X.cpp.

33. Edit Makefile

Since we need to cross-compile for Bone, and native compile with g++ for PC, Makefile can be constructed as follows:

```
## 5_WebCam_SI / c_VideoFunctionality_SDL_320 Makefile
all: Camera Viewer
```

```
## CC specifies which compiler we're using
CC = g++
# COMPILER_FLAGS specifies the additional compilation options we're using
# -w suppresses all warnings
COMPILER_FLAGS = -g - w
# LINKER_FLAGS specifies the libraries we're linking against
LINKER_FLAGS = -1SDL2
LINKER_FLAGS2 = -1SDL2 -1SDL2_image
## Camera on Bone
Camera: Camera.c Send UDP.c
       arm-linux-gnueabihf-gcc -g -o Camera Camera.c Send_UDP.c
## Viewer using SDL2 on PC
Viewer: Viewer.cpp Recv UDP.cpp
       $(CC) -o Viewer Viewer.cpp Recv UDP.cpp $(COMPILER FLAGS) $(LINKER FLAGS2)
clean:
       rm *~ Camera Viewer
```

34. Build

Type

```
$ make clean
$ make
arm-linux-gnueabihf-gcc -g -o Camera Camera.c Send_UDP.c
g++ -o Viewer Viewer.cpp Recv UDP.cpp -g -w -lSDL2 -lSDL2 image
```

35. Test

Camera on Bone as root

Set WebCam format and resolution as 320x240 Jpeg using v4l2:

```
# v412-ctl --set-fmt-video=width=320,height=240,pixelformat=1
```

Confirm the Webcam format

```
# v412-ct1 -V
```

Format Video Capture:

Width/Height : 320/240
Pixel Format : 'MJPG'
Field : None
Bytes per Line: 0
Size Image : 230400
Colorspace : SRGB

Run camera to send with destion IP of PC and port of 4960:

```
# ./Camera -a 192.168.100.12 -p 4960
```

```
Args: Dev /dev/video0, fmt 2, io 1, fc 0, IP 192.168.100.12, port 4960 Init socket to IP 192.168.100.12 with port 4960 ......
```

Viewer using SDL on PC

```
Simply, type
```

```
$ ./Viewer
```

Got a socket 6 with 4960.

Running RecvDisp Thread with data = 2

Recv_UDPs 0 24424, done 24424B. Display done.

Recv_UDPs 1 24452, done 24452B. Display done.

Success?

36. Test 2

Set WebCam format and resolution as 640x480 Jpeg using v4l2:

```
# v412-ctl --set-fmt-video=width=640,height=480,pixelformat=1
```

Repeat the test.

Can you send Jpeg image with size larger than 64K?

D. Test System Integration

Working directory

DesignLab/5_WebCam_SI/d_SystemIntegration.

Perform test on System Integration.

If successful, demonstrate to TA!

VII. Final Report

Discussion for the following question should be included in the report.

- 1) Compare formats: YUYV and Jpeg.
- 2) Search image storage format in commercial digital still camera and video camera.
- 3) Can you suggest another multitasking method for RoboCam? Can you do multitasking on PC without thread?
- 4) Is there any suitable graphic user interface other than SDL2? If yes, compare this method with SDL2.

- 5) Can one RoboCam on Bone support multiple simultaneous users?
- 6) Set your own topic to discuss related to Lab 5, and explain summary of your search result.

VIII. References

[1] Beaglebone Rev A6 System Reference Manual, http://beagleboard.org/static/beaglebone/latest/Docs/Hardware/BONE_SRM.pdf

[2] AM3359 Datasheet, AM335x ARM Cortex-A8 Microprocessors (MPUs) (Rev. J), http://www.ti.com/lit/ds/symlink/am3359.pdf

[3] Technical Reference Manual - AM335x ARM Cortex-A8 Microprocessors (MPUs) Technical Reference Manual (Rev. O), http://www.ti.com/lit/ug/spruh73o/spruh73o.pdf