Go2 SDK Development Guide

Search article titles

About Go2
Remote Controller
SDK Concepts 3
Application Development 7
Software Interface Services 19
Motion Services Interface V2.0
DDS Services Interface
Avoidance Services Interface
VuiClient Interface
RobotStateClient Interface
Motion Switcher Service Interface
Sports Services Interface
AI motion Services interface
Basic Services Interface
LiDAR Services Interface
Multimedia Services Interface
UWB Services Interface
Fault Services Interface
SLAM and Navigation Services Interfa
Aruco Recharge Service Interface
Odometer Services Interface
D1 Mechanical Arm Services Interface
ROS2 Services Interface
Python Services Interface
Case reference 8
Debugging Specification
FAQ

RobotStateClient Interface

Last Updated On：2025-11-26 17:38:10

This page contains content

RobotStateClient class
List of interface error codes:
Class and interface descriptio...
Service Name List

RobotStateClient class

RobotStateClient is a client provided by the device state service. Through RobotClient, it is convenient to control the internal service s of Go2, obtain service status, device status, and system resource usage information through RPC (some functional interfaces are n ot yet open).

List of interface error codes:

Error number	Error description	Remarks
5201	Service switch execution error	Server return
5202	The service is protected and cannot be turned on or off	Server return

Class and interface description:

Class Name	Creation and Deconstruction
RobotStateClient	explicit RobotStateClient(); ~RobotStateClient();

Function name	ServiceSwitch
Function prototype	int32_t ServiceSwitch(const std::string& name, int32_t swit, int32_t& status)
Function overview	Service switch.
Parameter	**name**: service name **swit**: switch, value 1 for on, 0 for off. **status**: service status after the operation is executed (0: on, 1: off)
Return value	Return 0 if the call is successful, otherwise return the relevant error code.
Remark	

Function Name	SetReportFreq
Function Prototype	int32_t SetReportFreq(int32_t interval, int32_t duration)
Function Overview	Set the frequency of service status reporting
Parameter	**interval**: Set the reporting time interval in seconds< BR>**duration**: Set the duration in seconds
Return Value	If the call is successful, 0 will be returned. Otherwise, relevant error codes will be returned
Note	Currently, the app's service status function is used and the refresh frequency is set

Function Name	Service List
Function Prototype	int32_t ServiceList(std::vector& serviceStateList);
Function Overview	Query the current service status.
Parameters	**serviceStateList**: List of current services and their statuses.
Return Value	Returns the list upon successful call, otherwise returns the relevant error code.
Remarks	List format: Name: Service name, Status: Status, Protect: Protected status

Service Name List

Service Name	Description
sport_ mode	Main motion control service （The software version is less than 1.1.6）
mcf	Main motion control service （The software version is greater than or equal to 1.1.6）
basic_ service	underlying service
chat_ go	Clumsy Dog Service
net_ switcher	Net switch
obstacles_ avoidance	Obstacle Avoidance Service
ota_ box	OTA firmware upgrade service
unitree_ lidar	Radar Services
utrack	accompanying services
video_ hub	Video Source Service
webrtc_ bridge	webrtc communication service
vui_ service	Offline voice service

Helpful
Feedback

The PDF has been downloaded. Rate us: