


# **Fading**

### Overview



This example demonstrates the use of analog output (Pulse Width Modulation (PWM)) to fade an LED. PWM is a technique for getting an analog-like behavior from a digital output by switching it off and on very fast and with different ratio between on and off time.

## Specification



### Pin definition

It is the definition of LED pin Long pin -> + (VCC) Short pin -> - (GND)

# Hardware required

Material diagram	Material name	Number
—(III)—	220/330Ω resistor	1
	LED	1
	USB Cable	1
	UNO R3	1
	Breadboard	1

---Designed by Smraza Keen


smraza

V1.0

Jumper wires

Several





Note: An LED connected to digital output pin 5 (D5) through a 220 ohm resistor.

## Sample code

Note: sample code under the Sample code folder

```
int ledPin = 5;  // LED connected to digital pin 5
void setup() {
   // nothing happens in setup
}
```

smraza

```
V1.0
void loop() {
  // fade in from min to max in increments of 5 points:
  for (int fadeValue = 0; fadeValue <= 255; fadeValue += 5) {
    // sets the value (range from 0 to 255):
    analogWrite(ledPin, fadeValue);
    // wait for 30 milliseconds to see the dimming effect
    delay(30);
 }
  // fade out from max to min in increments of 5 points:
  for (int fadeValue = 255; fadeValue >= 0; fadeValue -= 5) {
   // sets the value (range from 0 to 255):
    analogWrite(ledPin, fadeValue);
    // wait for 30 milliseconds to see the dimming effect
    delay(30);
 }
}
```

### Language reference

**Tips**: click on the following name to jump to the web page. If you fail to open, use the Adobe reader to open this document.

```
+= (add assign)
```

-= (subtract assign)

<= (less than or equal to)

>= (greater than or equal to)

### **Application effect**

You'll see that LED has the effect of breathing light.