
CoreEP2C8

- 1. Hardware Description
- 1.1 What's On Board
- 1.2 Interfaces
- 1.3 Hardware Setup
- 2. Examples
- 2.2 Source Code
- 3. Schematic
- 3.1 Schematic Circuit Diagram
- 3.2 Tcl script
- 4. Download
- 4.1 Download to FPGA
- 4.2 Download to FLASH



Welcome to Www.Wvshare.Com for Easy, Fast & Safe online purchase!

1.1 What's on the CoreEP2C8



- 1. EP2C8Q208C8N: the ALTERA Cyclone II FPGA device which features:
 - Operating Frequency: 50MHz
 - Operating Voltage: 1.15V~3.465V
 - O Package: QFP208
 - o I/Os: 138
 - LEs: 8K
 - o RAM: 165kb
 - O PLLs: 2
 - O Debugging/Programming: supports JTAG
- 2. AMS1117-3.3 (on bottom side), 3.3V voltage regulator
- 3. AMS1117-1.2 (on bottom side), 1.2V voltage regulator
- 4. EPCS16 (on bottom side), onboard serial FLASH memory, for storing code
- 5. Power indicator
- 6. LEDs
- 7. Reset button
- 8. nCONFIG button: for re-configuring the FPGA chip, the equivalent of power reseting
- 9. 50M active crystal (on bottom side)
- 10. JTAG interface: for debugging/programming
- 11. FPGA pins expander, VCC, GND and all the I/O ports are accessible on expansion connectors for further expansion

© 2090 Waveshare Electronics. All rights reserved.

Owned by Waveshare International Ltd.

Thank you for choosing our products!

If you have any question or suggestion, please contact us via email: service@wvshare.com

1 sur 1