# DongleSense

User guide / EN - Getting started

https://hellohvbert.github.io/donglesense/

## Important: do not hold the button while plugging in

Plug the adapter into your computer with its button released. Holding the button starts service mode instead of normal operation. Entering this mode does not erase the software, but copying an unsuitable file onto the adapter can replace it and stop the adapter working properly. If it appears as a drive, do not copy anything to it. Unplug it, then plug it back in without pressing the button.

## 1. Plug in the adapter

Plug the adapter into a computer USB port. It is ready to use - you do not need to install anything on it. Your controller will connect wirelessly to the adapter.

## 2. Press the adapter button

With no controller connected, briefly press the adapter button once. Release it and wait about one second. The adapter is now ready to connect to your controller.

## 3. Connect your controller

Hold the PlayStation logo button and the small Create button to the left of the touchpad together. Release them when the light rapidly flashes blue. Wait for the connection. Do not add the controller in your computer’s Bluetooth settings.

## 4. Open the settings

Open DongleSense in Chrome or Edge. Click “Connect DS5 Bridge”, select the adapter from the list and confirm. Check that the page shows your controller as connected.

# The adapter button

USB configurator / beta

## One short press

If no controller is connected, the adapter starts waiting for a new controller. If one is connected, it disconnects but remains remembered. Wait about one second after pressing.

## Two short presses

Restart the adapter. Wait about one second for this to happen.

## Three short presses

Start service mode. You do not need this to play or change settings. If you start it by accident, do not copy anything onto the adapter; unplug it and plug it back in with the button released.

## Hold for about 1.5 seconds

Warning: the adapter forgets all remembered controllers and disconnects the current one. It then becomes ready for a new connection. Only use this when you want to forget saved controllers, then follow the steps on the first page.

# First connection

USB configurator / beta

## 1. Prepare the adapter and controller

Plug the adapter into a computer USB port. After pairing as described on the first page, the controller connects to the adapter wirelessly. Use the page to adjust your controller settings.

## 2. Open the panel

Use Chrome or Edge on your computer and the address on the first page. If DS5 Bridge or AudioHelper is running, fully exit it using its icon next to the clock. Disconnect the adapter in other open website tabs.

## 3. Connect and read

Click “Connect DS5 Bridge”, select the USB adapter and confirm. The initial connection only reads device state. Check the success message and controller status. Battery and signal strength are reported by the adapter.

## 4. Apply settings

Change a value and click “Apply changes”. Moving a slider or choosing a color only edits the form. The page checks that the adapter accepted the change. “Discard” restores the form to the last reading.

## Local profile and power

“Save reading as profile” stores the settings read from the device in this browser. “Load profile into form” prepares the values; only “Apply changes” sends them to the device. Settings may return to previous values after power is disconnected. After power is disconnected, reconnect, read the current state, then load and apply your profile if needed.

# Settings and help

USB configurator / beta

## Controller and Audio

Controller: haptics gain, idle disconnect and timeout. The rumble test produces short classic vibrations, not every type of in-game vibration; it requires a connected controller and no unapplied changes. Audio: speaker volume, speaker gain and microphone mute. Audible results also depend on the sound source and game/system configuration.

## Adapter and controller lightbar

The Adapter tab includes the adapter LED, wake, disconnect on USB suspend and the controller sleep shortcut. Choose a controller color on the palette; set brightness with the separate slider. “Keep selected color” prevents games from overriding it. Confirm each change using “Apply changes”.

## Keyboard and profiles

Use Tab to move between controls. On the palette, left/right arrows adjust saturation and up/down adjust color value; hold Shift for larger steps. Profiles belong to the current browser and website address. A profile from a local copy of the website does not move to the online site automatically; clearing site data may delete it.

## Connection or apply problems

Adapter in use by another app: exit the desktop app from its tray icon and disconnect other tabs. Cancelled selection: connect again. Disconnected adapter: reconnect and read again. Settings conflict: refresh before editing. If the adapter does not respond or only some changes are applied, reconnect and check actual values - do not assume every change was applied or rolled back.

## Scope and beta status

Trigger Lab, remapping, custom chords, controller mode switching and system audio capture are not implemented. The adapter software stays unchanged. Connection, color, classic rumble and profile restoration were checked on the user’s adapter; full audio, wake and cross-browser acceptance tests remain open.