DongleSense

User guide / EN - First pairing and the Pico button

https://hellohvbert.github.io/donglesense/

1. Connect the prepared adapter

Plug the Pico into a computer USB port without holding BOOTSEL. Your adapter already has firmware, so do not flash the UF2 again. The controller connects wirelessly to the Pico; the Pico connects to the computer over USB.

2. Open pairing on the Pico

With no controller connected, briefly press BOOTSEL once and wait about one second. The adapter opens its pairing window.

3. Put the controller in pairing mode

Hold Create and PS together until the lightbar rapidly flashes blue. Wait for the controller to connect to the Pico. Do not add it in Windows Bluetooth settings. Then open DongleSense and click “Connect DS5 Bridge”.

BOOTSEL: one or two presses

One brief press opens pairing when no controller is connected, or disconnects a connected controller while keeping its saved pairing. Two brief presses reboot the Pico normally. Single- and double-press gestures take effect after about one second while the Pico waits for another press.

BOOTSEL: three presses or a hold

Three brief presses reboot into firmware flashing mode, where the Pico appears as a USB drive. Holding for about 1.5 seconds deletes all saved controller pairings, disconnects the current controller and opens a fresh pairing window. Use the hold gesture only when you intend to forget saved controllers.

Holding the button while plugging in

Holding BOOTSEL while plugging an unplugged Pico into USB starts firmware flashing mode, not normal pairing. For everyday use and first pairing of a prepared adapter, plug it in without holding the button.

First connection

USB configurator / beta

1. Prepare the adapter and controller

Plug the adapter into a computer USB port. After pairing as described on the previous page, the controller connects to the adapter wirelessly. This panel does not pair controllers or update firmware. This guide covers the DS5 Bridge profile; older awalol guides do not apply.

2. Open the panel

Use Chrome or Edge on a computer with WebUSB support. Open the link below. Exit DS5 Bridge and AudioHelper from the system tray, and disconnect the adapter in other configurator tabs.

3. Connect and read

Click “Connect DS5 Bridge”, select the USB adapter and confirm. The initial connection only reads device state. Check the success message and controller status. Battery and RSSI values are reported by the adapter, not independently measured.

4. Apply settings

Change a value and click “Apply changes”. Moving a slider or choosing a color only edits the form. The panel verifies the adapter acknowledgement and readback. “Discard” restores the form to the last reading.

Local profile and power

“Save reading as profile” stores the settings read from the device in this browser. “Load profile into form” prepares the values; only “Apply changes” sends them to the device. Adapter settings belong to the current session - the panel does not save them to flash. After power is disconnected, reconnect, read the current state, then load and apply your profile if needed.

Settings and help

USB configurator / beta

Controller and Audio

Controller: haptics gain, idle disconnect and timeout. The rumble test produces short classic vibrations, not HD haptics; it requires a connected controller and no unapplied changes. Audio: speaker volume, speaker gain and microphone mute. Audible results also depend on the sound source and game/system configuration.

Adapter and controller lightbar

The Adapter tab includes the adapter LED, wake, disconnect on USB suspend and the controller sleep shortcut. Choose a controller color on the palette or enter HEX/RGB; set brightness with the separate slider. “Keep selected color” prevents games from overriding it. Confirm each change using “Apply changes”.

Keyboard and profiles

Use Tab to move between controls. On the palette, left/right arrows adjust saturation and up/down adjust color value; hold Shift for larger steps. Profiles belong to the current browser and website address. A localhost profile does not move to the online site automatically; clearing site data may delete it.

Connection or apply problems

Busy interface: exit the desktop app from its tray icon and disconnect other tabs. Cancelled selection: connect again. Disconnected adapter: reconnect and read again. Settings conflict: refresh before editing. After a timeout or partial apply, reconnect and check actual values - do not assume every change was applied or rolled back.

Scope and beta status

Trigger Lab, remapping, custom chords, controller mode switching and system audio capture are not implemented. Firmware stays unchanged. Connection, color, classic rumble and profile restoration were checked on the user’s adapter; full audio, wake and cross-browser acceptance tests remain open.