



HOW TO MAKE TIN CAN LANTERNS

Materials

- * Tin cans
- * Cloth
- * White spirit
- * Sand
- * Paper & pencil
- * Sticky tape
- * Fabric bag filled with sand
- * Masonry nails
- * Hammer
- * Small mole grips
- * Wire coat hangers
- * Small bolt cutters
- * Ring-bending pliers
- * Newspaper
- * Spray paint



1 Remove the label and any blobs of glue from the can. Pack the can with sand, top up with water, and freeze overnight.



2 Draw your design on a piece of paper to fit the size of the can. Tape in place. If you're drawing your own design, ensure that the gap between holes is at least as large as the diameter of each hole.



3 Place the can on the sandbag. Punch holes in the can. Place the can in the freezer for about 30 minutes after each 10 minutes of work to ensure the can remains solid. If you're making several lanterns, work on them in rotation.



4 Once your design is complete, punch a pair of holes opposite each other 1cm ($\frac{3}{8}$ in) below the top of the can for fitting the handle. Remove the sand. Make a handle out of a 25cm (10in) length of wire, following making wire handles on p.167.