
High heat
A dishwasher uses high heat to clean household dishes and cutlery. Due to the heat, some items may melt or warp when washed in a dishwasher.




ENERGY-EFFICIENT DISHWASHERS USE LESS WATER AND ENERGY THAN WASHING DISHES BY HAND


Water softeners

Some areas have hard water that inhibits detergents, leaves streaks, and damages heating elements. Hard water contains a higher concentration of minerals such as calcium and magnesium compounds. An ion exchanger passes hard water through resin beads loaded with sodium ions. Unwanted ions are attracted to the beads and exit the water as they displace the beads' sodium ions, leaving the water softened and lower in minerals.

KEY
- Calcium
- Magnesium
- Sodium
- Iron
- Manganese



Softening cycle
As hard water flows through the tank of resin beads, its ions are attracted to the beads, displacing sodium ions.



Regeneration cycle
Salt water is flowed through the resin beads, replenishing the beads with sodium ions and displacing magnesium, calcium, and other unwanted ions.

DISHWASHER TABLETS

Detergent tablets contain a cocktail of chemicals with different roles. These include chlorine and oxygen bleaches to dissolve food stains, as well as enzymes that attack the bonds between atoms of protein and starch molecules in foods, making them easier to wash away.

