Moist heat Sterilization: -

Boiling: At a temperature of 100°C boiling for 3 to 5 minutes kill microorganisms except spore bearing organisms.

- This method is suitable for enamel, metal, glass, rubber wares.

Points to remember: -

- The article must be cleaned by scrubbing to remove the organic matter.
- Great care should be taken for glass articles and they should be wrapped with cloth and put in cold water and then brought to boil.
- The organic matter which will coagulate around the organism and protect them.
- Testing material to check effectiveness of sterilization.

Autoclaving (Above 100°C temperature)

Spore bearing organism Ex. Clostridium tetani are killed by steam under pressure.

Autoclave



Nursing-Gen_Chapter 06.indd 105 07/05/18 12:51 PM