1. Too much main spring tension cause the jerky movement of the Carriage

2. Too low main spring tension cause the sluggish movement of the carriage.

There are other two main tensions in the Typewriter:

1. Key tension.

2. Touch Regulator tension.

Draw Cord: It is also called as Draw Band or Draw Strap. One edge of the

Draw Cord is hooked with the mainspring drum and the other edge is hooked with

carriage end. Due to mainspring tension the connected draw cord pulls the

carriage towards left. If the draw cord is cut off, the carriage will not move.

Type Guide or Center Guide: It is also known as Common Centre Printing Point. It allows only one type bar to enter through and strike against the Cylinder while typing. It is cleaned with the Chamois Leather.

Type Heads:

The following are the kinds of Type Heads/ Type faces:

1. Pica … 10 Letters per inch

2. Elite … 12 Letters per inch

3. Roman … 09 Letters per inch

4. Gothic

5. Italics.

6. These typefaces should be cleaned with Petrol.

Ribbon Movements: There are three Ribbon Movements of the carriage.

1.Up and down Movement

2.Lengthwise Movement

3.Automatic Reverse Movement

Up and down Movement is used to utilize the full Width of the Ribbon.

Lengthwise Movement is used to utilize the full length of the Ribbon.

Automatic Reverse Movement is used to utilize the Ribbon for many times.

Ribbon:

Ribbon take is made of cotton or silk, dipped in ink. It makes the impression visible on the paper.

There are two kinds of Ribbon:

1. Record Ribbon: It is used for ordinary purpose

2. Copying Ribbon: It is used for copying purpose

Double colour Ribbon is called 'Bi-chrome Ribbon'

To preserve the Ribbon from moisture or from dryness the typewriter should be

covered soon after the work is over. Normal length of the ribbon is 8 yards and ½

inch. Width.

Questions:

1. Where is the Mainspring drum Located?

2. What is the use of Mainspring?

Typography_unit09.indd 326 05-03-2019 12:12:42