- Sew a square piece of tape at the raw edge.
- Place the zipper on the sewn lap and stitch through the edges holding the fabric edge.
- Cover the zipper edges with a small square piece of tape, tack it first and then sew it.
- Hem the raw edges neatly to finish the zip.

12.4.2.5 Faced Placket Open

It is one of the simplest methods of finishing a neckline. It is mostly used for infants, children and night dresses.

Method of Sewing Faced Placket Open:

- Cut a placket open for the required length at the centre back or front
- Place the facing piece right sides on the garment and make row of stitches
- Turn the facing to the wrong side and then top stitch
- Hem neatly to finish the facing

12.4.3 Fastener

Fasteners are the items which are used to close a garment opening. They are decorative as well as functional. Care should be taken while selecting a fastener as they must be rust free and withstand laundering. They can be selected to match the colour, design and texture of the garment. Decorative fasteners are sewn to add beauty to the garment. Example: cartoon shaped button on the centre front line of baby's frock with back opening. Functional buttons sewn as closure to the garment, it helps in fitting the garment very close to the body. Example: Shirt buttons sewn in the centre front line of a men's shirt. Fasteners should be always sewn on two layers of fabric to ensure strength. Fasteners can be conspicuous or inconspicuous. **Example:** Shirt buttons on the shirt centre front line and hook in women's blouses respectively. Generally, fasteners are sewn in garments to create a left lap overlap the right for women and vice-verse for men's garment.

12.4.3.1 Types of Fasteners

12.4.3.1.1 Press Button

Press buttons are available in different sizes and weights and are used to hold edges that will not have much strain when the garment is worn. It has two sections: a stud and a socket. The stud is attached on the wrong side of the overlap and the socket comes over its impression on the underside of the placket. The press buttons have four holes into which buttonhole stitches are made to hold them firmly to the garment. This is best suited for kids garments (Figure 12.28).



Figure 12.28 Press Buttons

12.4.3.1.2 Hook and Eyes/Loops

Hook and Eye / loops are generally used in plackets. The hook is placed about 0.5 cm inside the finished edge on the wrong side of the overlap and the eye or loop comes on

TDD_Final_Chapter12.indd 136 21-02-2019 12.35.49 PM