
Activity 3

Create your own electromagnet

You are given a long iron nail, insulation coated copper wire and a battery. Can you make your own electromagnet?

Know Your Scientist

Michael Faraday (22nd Sep,1791–25th Aug, 1867) was a British Scientist who contributed to the study of electromagnetism and electrochemistry. His main discoveries include the principles underlying electromagnetic induction, diamagnetism and electrolysis.



5.7.2 Fleming's Right Hand Rule

Stretch the thumb, fore finger and middle finger of your right hand mutually perpendicular to each other. If the fore finger indicates the direction of magnetic field and the thumb indicates the direction of motion of the conductor, then the middle finger will indicate the direction of induced current. Fleming's Right hand rule is also called 'generator rule'.




Figure 5.17 Fleming's right hand rule

5.8 Electric generator

An alternating current (AC) generator, as shown in Figure 5.18, consists of a rotating rectangular coil ABCD called armature placed between the two poles of a permanent magnet. The two ends of this coil are connected to two slip rings S_1 and S_2. The inner sides of these rings are insulated. Two conducting stationary brushes B_1 and B_2 are kept separately on the rings S_1 and S_2 respectively. The two rings S_1 and S_2 are internally attached to an axle. The axle may be mechanically rotated from outside to rotate the coil inside the magnetic field. Outer ends of the two brushes are connected to the external circuit.




Figure 5.18 AC generator

When the coil is rotated, the magnetic flux linked with the coil changes. This change in magnetic flux will lead to generation of induced current. The direction of the induced current, as given by Fleming's Right Hand Rule, is along ABCD in the coil and in the outer circuit it flows from B_2 to B_1. During the second half of rotation, the direction of current is along DCBA in the coil and in the outer circuit it flows from B1 to B2. As the rotation of the coil continues, the induced current in the external circuit is changing its direction for every half a rotation of the coil.

To get a direct current (DC), a split ring type commutator must be used. With this arrangement,

IX_SCI_EM_Unit-05_PHY.indd 60 12-02-2020 14:15:33