A distance equal to the 3/5th of the height of the letters has to be left between two successive words. The space between two lines should be equal to 1 ½ times the height of the letters.

SIZE OF LETTERS

The size of letters in engineering drawing is the height of the letters. B.S.I recommends standard sizes of lettering for various features and they are listed below

SI. No	Features	Size(Height in mm)
1	Drawing Numbers, Letters indicating cutting plane section	10, 12
2	Title of the drawing	6, 8
3	Sub-titles and headings	3, 4, 5 & 6
4	Material List, Dimensioning, Schedules , notes	3, 4 & 5
5	Tolerances Alteration entries	2 & 3

TYPES OF LETTERS

The lettering in which the alphabets are written with uniform thickness is known as Gothic lettering . Gothic lettering may be done on single stroke and double stroke. Double stroke letters are thicker than single stroke letters.

ITALIC PRINTING IS

free hand gothic

OR ROMAN LETERING

Types of letters

1. Vertical letters
   a) Upper case letters (capital)
   b) Lower case letters

2. Inclined letters
   a) Upper case letters (capital)
   b) Lower case letters

Vertical Letters

If the direction of alphabets and numerals is vertical, the letters are know as vertical letters, Both upper case and lower case letters are written in this fashion.