6. When it is necessary to handle equipment that is plugged in, be sure hands are dry and when possible wear non conductive **gloves & shoes** with rubber soles.
7. If it is safe to do so, work with only **one hand**, keeping the other hand at your side or in your pocket, away from all conductive material.
8. Equipment producing a **"tingle"** should be disconnected and reported promptly for repair.
9. **Drain capacitors** before working near them and keep the short circuit on the terminals during the work to avoid electrical shock.
10. When it is necessary to touch electrical equipment (*for example, when checking for overheated motors*), use the back of the hand. Thus, if accidental shock were to cause muscular contraction, you would not "freeze" to the conductor.
11. Do not rely on grounding to mask a defective circuit nor attempt to correct a fault by inserting another fuse or circuit breaker, particularly one of a larger capacity. Before replacing a fuse or circuit breaker, **check the problem** that caused earlier was rectified.
12. **Insulate** all electric contacts and conductors. Never splice wires together and conceal them within a wall without a junction box. An accessible junction box should always be used to join wires.
13. Never use an aluminium or steel ladder while working on any receptacle at height in your home. An electrical surge will ground and the whole electric current will pass through the body. Use only bamboo, wooden or a fibre glass ladder for electrification work.
14. Do not store **highly flammable liquids** near electric supply.
15. Minimize the use of electrical equipment in cold rooms or other areas where condensation is likely.
16. Keep the length of **extension cords** to restricted length.
17. **Unplug** cords by gripping the plug and, do not by pulling the cord.
18. **Do not wear** loosed clothing or ties near electrical equipment.
19. If a person was affected by an electric shock, immediately disconnect the power source of the circuit breaker or pull out the plug using a leather belt.
20. Never work on **live** equipment.
21. **De-energize** open experimental circuits and equipment to be left unattended.
22. Never use equipment with frayed cords, damaged insulation or broken plugs.
23. Be aware that interlocks on equipment disconnect the high voltage source when a cabinet door is open, but the power for control circuits may remain ON.
24. Try to cover the live wire with cap while working on circuit panels. The cap acts as an insulation and helps to prevent electric shock.

EMA_English_Practical.indd 204 11/9/2020 3:56:09 PM