6.2.4.1 Rubble Masonry



In this masonry, stones are not dressed. They are used in the masonry as obtained from the quarry. It may be shaped with the help of hammers just by removing excess projection before using in the masonry.

Types of Rubble Masonry

I. Coursed rubble masonry.
ii. Un-coursed rubble masonry.
iii. Random rubble masonry.
iv. Dry rubble masonry.

Coursed Rubble Masonry

In this type of rubble masonry, the height of stones vary from 5cm to 20cm. The stones are sorted out before the work starts. The masonry work is then carried out in courses such that stones in a particular course are of equal heights. This type of masonry is used for the construction of public buildings, residential buildings, etc.



Un-coursed Rubble Masonry



In this type of rubble masonry, the stones are not dressed. But they are used as they are available from the quarry, except breaking some corners. The courses are not maintained regularly. The larger stones are laid first and the spaces between them are then filled up by means of spalls. The wall is brought to a level at every 30 cm to 50 cm. This type of rubble masonry being cheaper and is used for the construction of compound walls, godown, garages, labour quarters, etc.

Civil_English_Unit_6.indd 140 12/21/2019 4:39:52 PM