

Circular Arch



Inverted Arch

7.1.6 Difference Between Arches and Lintels

S.No	Arches	Lintels
1	Generally curved in shape.	Horizontal in shape.
2	Gives excess rises over door and window openings.	There is no excess rises in lintels.
3	Good for uniformly distributed loads and weak in point loads.	Strong in uniformly distributed loads as well as point loads.
4	Joints should be in radial shape.	Joints should be vertical.
5	Supported at the abutments and piers.	There is no supports like piers and abutments.
6	Arches gives beautiful appearance to the buildings.	Gives ordinary appearance to the buildings.

Civil_English_Unit_7.indd 159 12/21/2019 4:57:56 PM