

NOTE: Never use ordinary cheap quality pencils on your drawing sheet.



Keep your pencil sharp: A dull pencil produces fuzzy lines. Only a sharp pencil produces black and sharp lines that sparkle with clarity. Lead is sharpened to conical point (or) chisel edge by rubbing on an emery paper. Conical point is used for lettering and freehand sketching. Chisel edged pencil is used for drawing lines.



Micro-tip pencils

Micro-tip pencils / clutch pencils with 0.5mm thick leads of grades HB, H and 2H are preferred than wooden pencils, as they need no sharpening.



Microtip Pencils



What is the birth place of pencil?

Germany was the birth place of the first mass produced pencils in 1662.

The discovery of a large graphite deposit in Borrowdale, England in 1564.

Later, the graphite was inserted into hollowed – out wooden sticks and thus the wood cased pencil was born at Nuremberg, Germany

Search link: http://en.m.wikipedia.org>swiki>pencil. www.historyofpencils.com

1.1.3.12 Pencil Eraser

Pencil eraser ('it is not rubber' call it 'eraser') is used to erase unwanted lines, etc. A non-dusting good quality eraser should be used.

Civil_English_Unit_1.indd 10 12/21/2019 1:06:36 PM