Building Construction

# 13 SETTING OUT OF FOUNDATION FOR SINGLE ROOM BUILDING

## Aim:

To mark the center line of a building for excavation of foundation.

TJQZ2J

## Apparatus and Materials required

1. Measuring Tape
2. Tri Square
3. Bundle of String
4. Hammer
5. Pegs
6. Lime Powder

## Procedure

1. All the vegetations in the construction site are removed and levelled.
2. Study thoroughly the plan of building. For example, take the inner measurements of a room as 4.80 × 3.30m.
3. Prepare the centre line sketch for that plan.
4. The wall thickness of the building is 0.20m, so the centre line distance of the room is 5.00 × 3.50m.
5. Mark the center line of front wall 1 & 2. Tie a string tightly in it.
6. Mark the center line distance of the front wall in it and name it as 'A' and 'B'.
7. Set out a perpendicular line from 'B'. Extend the ends and name it as 3 and 4. Tie a string in it also.
8. Mark the point 'C' as per centre line sketch in it.
9. Continue the same procedure until it reaches point 'A'.
10. Now, we can get a rectangle bounded by strings.
11. The diagonals 'AC' and 'BD' should be checked for the correctness. (AC = BD).
12. Mark the half of the width of the foundation on either side of the centre line using lime powder.



XI_Civil_Practical_English.indd 247 12/21/2019 5:50:43 PM