cleaned with petrol or paraffin and can be reused. Figure 6.4.3 shows the Oil Wetted Type Air Cleaner.

6.5. FUEL PUMP

The required amount of fuel (for producing power) pumped from the fuel tank to the combustion chamber is transferred by the device called fuel pump.

It is classified according to the fuel used as,

1. Fuel Pump (Petrol Engine)
2. Fuel diesel pump (diesel engine)

6.5.1 Petrol Fuel Pumps

A fuel pump is used to transfer the fuel from the fuel tank through the filter with appropriate pressure to the float chamber of the carburettor in gasoline engines to drive the vehicle. Petrol Fuel pumps are classified in two types as

1. A.C. Mechanical Fuel Pump
2. S.U. Electric Fuel Pump



Fig 6.5.1(a) A.C. Mechanical Fuel Pump



Fig 6.5.1(b) S.U. Electric Fuel Pump




Figure 6.5.1 (a) Schematic of A.C. Mechanical Fuel Pump.




Figure 6.5.1 (b) S.U. Electrical Fuel Pump.

6.5.2 Diesel Fuel Injection Pump

Unlike in petrol engines, in diesel engines diesel stored in the fuel tank is sucked by the Diesel fuel injection pump. The fuel from the fuel tank is passed through the fuel filter and feed to the fuel injection pump. The fuel injection pump develops high pressure and the pressurized fuel is sent to the fuel injector and sprayed into the engine's combustion chamber. This fuel injection pump is classified into two types. They are,

AM_Unit_06.indd 120 31-01-2019 17:49:22