| | |
|---|---|
| 8. There may be blockages in the radiator fins. | Have to be removed or cleaned. |
| 9. There may be an auto ignition. | Has to be corrected. |
| 10. There may be changes in valve timing and ignition timing. | Has to be corrected. |
| 11. There may carbon deposition in the cylinder head, valves, piston and combustion chamber. | Need to be cleaned by De carbonizing technique. |
| 12. There may be defects in break or clutch | Have to be corrected. |
| 13. The vehicle may be over loaded. | Enough amount of goods to be carried. |
| 14. There may be blockages in the exhaust tail pipe. | Have to be removed. |
| 15. Engine bearing may get damaged or broken. | Has to be changed with a new one. |
| 16. There may be blockages in air cleaner or air inlet manifold. | Have to be removed or corrected. |
| 17. Fuel injection timing may be incorrect. | Has to be checked and corrected. |

**Over noise from water pump:**

| Causes | Remedies |
|---|---|
| 1. Impeller in the water pump may be loosened. | Has to be tightened. |
| 2. Pulley in the pump shaft may be loosened. | Has to be tightened. |
| 3. Impeller may rotate unevenly inside the pump housing. | Has to be fixed at the right place. |
| 4. Bearing in the water pump may damage or lubricating oil may not be there in the bearing. | Oil has to be applied or changed with new bearing. |
| 5. Impeller may be broken. | Has to be checked and corrected. |



AM_Unit_07.indd 153 31-01-2019 17:50:51