1. Lubricating Oil Pressure Gauge
2. Engine Temperature Gauge
3. Fuel Gauge
4. Door Open Signal Indicator
5. Handbrake signal indicator

The following indicators are used to alert the driver through sound with the help of buzzer.




Figure 1.6.1.1 Seat Belt Alarm System

1.6.1.1 Seat Belt Alarm System

One should wear a seat belt while driving. If a driver or person forgets to wear the seat belt, then it will alert the driver. Shown in Figure 1.6.1.1.

1.6.1.2 Headlight Alarm System

Most modern vehicles have inbuilt headlight alarms or automatic headlight switch off functions. Sounds an audible alarm when the ignition is turned off while the head lights are turned on.

1.6.1.3 Reverse Parking Sensor

Parking sensors are proximity sensors for road vehicles designed to alert the driver to obstacles while parking. Car Parking Sensor suitable for parallel parking, backing up your car, distance keeping, especially in dark, rain or any other poor rear visibility conditions.

1.6.1.4 Anti-Theft Car Alarm

Anti-theft systems are designed to prevent your vehicle from being stolen. It generates a loud alarm when there is a theft attempt. When the intruder opens the door, the circuit senses the attempt of theft and the alarm will be activated. An anti-theft system may also integrate a car alarm or it might be just an engine immobilizer.

AM_Unit_01.indd 12 12/20/2019 4:19:13 PM