10.5 ENGINE TUNE UP

It is a process of inspecting, servicing and replacing the important components of engines like carburettor, spark plug, timing gears, fan belt etc. based on their condition. This will help to improve the performance and reduce the maintenance cost.

10.5.1 ENGINE TUNING PROCEDURE

1. Start the engine with loose condition of spark plug and remove the carbon powder and moisture. Then switch of the engine and remove the spark plug.
2. Checking of engine compression ratio
3. If engine's compression ratio is low then engine is over hauled and rectify the problems. After rectification of compression ratio, spark plug to be fixed.
4. To remove and cleaning of distributor cap. Then check the wearing of cap and wire. If wearing is more then change the new one.
5. To check the distributor's rotor condition. If damaged, change the new one.
6. To check the H.T. wires of distributor. If any damage in that wire, should be replaced.
7. To check the main mechanism of distributor.
8. To check the vacuum mechanism.
9. To check and cleaned the C.B. points, then set the proper gap. If C.B. point damaged then it should be replaced.
10. Again fix the distributor gap and connect the wires properly.
11. To check the battery and maintain the distilled water level.
12. To check the battery wires and rectify the problems.
13. To check the dynamo / alternator when battery is low power.
14. To check the engine belt conditions. If damaged change the fan belt.
15. To check the engine valve clearance and set properly.
16. To tight the inlet manifold's bolts when leakages occurs.
17. To check the leakages, tightness and straightness of fuel pipe lines.
18. To check the leakages in the cooling system and hose pipes. If coolant level is low then maintain the level
19. To check the accelerator connection of and adjust the connection.
20. To check the crankcase ventilation system.
21. To check the quality of engine lubrication oil and if required, change the lubrication oil.
22. To remove and cleaned the carburetor and air cleaner. If required change the air cleaner and to check the chock valves.
23. To check the ignition timings and if required set properly.
24. To check the carburettor's idle speed adjusting screw and if required adjust the same.
25. To check the light and horn. Head light to be adjusted properly.
26. To check the steering system's smoothness and freeness. If required rectify the system.
27. To check the wear, excess movement and tightness of suspension system and shock absorber system.

AM_Unit_10.indd 216 31-01-2019 18:04:27