




Vernier Caliper





(d) Vernier reading

A model reading
MSR = 2.3 cm ; VSC = 4 divisions;
Reading = [2.3 cm+(4x0.01cm)] = 2.34 cm

Zero error

When both jaws closed together, Zero error occurs when zero on the main scale coincides with the zero on the veriner scale.

Positive error

When both jaws closed together, the vernier scale zero is more than the zero on the main scale.

Negative error

When both jaws closed together, the vernier scale zero is less than the zero on the main scale.

If the error occurs, add or subtract from the measurement appropriately.

a) Outside Diameter

- Fix the given object in between the fixed jaw and movable jaw for external measurements.
- Using the adjusting screw, adjust and lock the locking screw.
- Now take the external measurement of the object.

AM_English_Practicals.indd 238 12/20/2019 5:49:59 PM