Machine ii) Portable Drilling Machine. Fig 2.3.4(a) shows the Drilling Machine.






Figure 2.3.4(a) Pillar Type Drilling Machine

2.3.4(b) Battery Charger

The battery charger is used to charge the batteries. It converts the alternating current into a direct current and makes the battery to be charged. Because the battery cannot be directly charged with alternating current. Figure 2.3.4(b) shows Battery Charger.



Figure 2.3.4(b) Battery Charger

2.3.4(c) Cylinder Boring Machine

Continues operation engine leads to wear on the cylinder walls. The energy of the engine is wasted by such wearing. Therefore, Cylinder Boring Machine is used to adjust the cylinder's inner diameter. Refer Figure 2.3.4(c).



Figure 2.3.4(c) Cylinder Boring Machine

2.3.4(d) Spark Plug Tester

In petrol engine at the end of the compression stroke, spark is ignited to burn the

AM_Unit_02.indd 41 12/20/2019 4:25:28 PM