



13 To remove the black finish, sand the charm again, once more working through the sanding pads from the 180 grit to the finest, the 280 grit. The longer you spend carefully sanding, the better the results will be. The black finish should remain in the details.



14 Once you are pleased with the finish, attach the jump ring and chain. Using two pairs of pliers, gently twist the ends of the jump ring away from each other and thread one end through the hole in the charm. Twist the jump ring closed, then thread the finished pendant onto the chain.

