the conductor itself acts as primary and the magnetic flux due to current flowing through the conductor cuts the secondary of CT. With the help of ammeter connected to the handle of the tong tester, the current flowing through the circuit can be measured. It is also called as clamp-on meter. This is also used to measure high voltage across any two points.

Handling procedure

i. Open the jaws of the tong tester and place them around the conductor.
ii. To avoid any harm in the circuit, select a higher scale-value first.
iii. Slowly decrease the scale value using selector switch if current is less.
iv. Measure the current of each line one by one.

Glossary

Deflecting torque	-	விலக்க சுழற்றுமை
Controlling torque	-	கட்டுப்படுத்தும் சுழற்றுமை
Damping torque	-	ஒடுக்கல் சுழற்றுமை
Moving iron	-	இயங்கு இரும்பு
Absolute instruments	-	தனிநிலைக் கருவிகள்
Spring control	-	வில் கட்டுப்பாடு
Gravity control	-	ஈர்ப்பு விசைக் கட்டுப்பாடு
Piston	-	உந்துத் தண்டு
Multiplier	-	பெருக்கி
Shunt	-	இணைத்தடம்
Analog multimeter	-	குறிமுள் பல்நோக்கு அளவுமானி
Digital multimeter	-	எண்ணிலக்க பல்நோக்கு அளவுமானி
Eddy current	-	சுழல் மின்னோட்டம்
Range	-	நெடுக்கம்
Galvano meter	-	மின்னோட்ட அளவி

BEE_ENG_Chapter_06.indd 98 12/27/2019 10:30:46 AM