Precautions

1. Do not touch the geyser, when the power supply is 'ON'.
2. Check the body of the geyser is electrically insulated, before and after dismantling of the geyser.
3. Before switching 'ON' the electric supply, ensure that the inner water tank of the geyser is filled with water.
4. After completion of the necessity of hot water, disconnect the electrical supply of the geyser.
5. When the geyser is not to be used for a long time, the water in the tank should be drained out by unscrewing the drain plug.

Result

The method of dismantling the given Geyser and identify the parts, testing the Geyser, identifying and rectifying its faults, and assembling the Geyser was carried with proper tools. Now the Geyser is working in good condition.

BEE_ENG_Pratical.indd 185 12/27/2019 10:54:34 AM