Average resistance value of the Running winding

$$R_{av} = \frac{Total\ Resistance\ value\ (R_T)}{No.\ of\ readings\ taken}$$

Result

The starting and running winding resistance of the given AC single phase capacitor type induction motor is determined by Ammeter-Voltmeter method, and also known about the short circuits in the windings.

BEE_ENG_Pratical.indd 197 12/27/2019 10:54:36 AM