

W A 54 M 7 V 20

W – Manufacturer's abrasive symbol

A – Types of abrasive – Aluminium oxide

54 – Size of abrasive – Medium

M – Grade of bond – Medium

7 – Structure of the grinding wheel – Dense

V – Types of bond – Vitrified

20 – Manufacturer's symbol

4.12 Mounting the grinding wheel

Great care must be take in mounting the grinding wheels on the spindle the following points are important in connection with mounting of grinding wheel.

KNGUXL

1. All wheels should be inspected before mounting to make sure that they have not damaged. The wheel is put on an arbor and is subjected to slight hammer blows. A clear, ringing, vibrating sound must be heard.
2. The grinding wheel should not be forced on the spindle and they should have an easy fit on the spindle.
3. The length of the lead bush should not be more than the width of the wheel face.





4. Flanges of equal diameter are fitted at both sides of the wheel. The flange diameter should enough to hold the grinding wheel conveniently. Atleast the flange diameter must be equal to the half of the grinding wheel diameter.
5. The sides of the wheel and the flanges should be flat. Flanges contact the wheel only with the annular clamping area.
6. Washes of compressible materials such as cardboard, leather, rubber etc. Not over 1.5 mm thick should be fitted between the wheel and its flanges. The diameter of washers may be normally equal to the diameter of the flanges.

XII BME_English version CHAPTER 04.indd 90 1/8/2020 1:43:07 PM