


8.7 Types of rotary pump

1. Gear pump
2. Vane pump
3. Lobe pump
4. Screw pump

Special pump

1. Bore-hole pump
2. Jet pump
3. Deep well submersible pump

8.8 Centrifugal pump

Main components of a centrifugal pump:

1. Prime mover
2. Impeller
3. Casing
4. Suction pipe
5. Delivery pipe

Prime mover

The prime mover of a pump may be an electric motor or an oil engine. It provides the rotational power to the shaft of the device.

Impeller

It is the rotating part in the device. Vanes or blades are arranged in series on it. The vanes are fitted on the shaft and rotated by the prime mover.

Casing

Casing is a hollow chamber surrounding the impeller. It is made as an air-tight unit. The sectional area of the casing gradually increases in the direction of the flow of liquid. This construction ensures the decrease is the velocity of the liquid and increase of the pressure.

Suction pipe

The top of the suction pipe is connected to the impeller (inlet). The bottom end is attached with a foot valve and a strainer.

Delivery pipe

The lower end of the delivery pipe is connected to the outlet of the pump. The liquid is pumped out through the other end of the pipe.

XII BME_English version CHAPTER 08.indd 144 1/8/2020 1:39:34 PM