


Figure 6.4.1.4 (b) Sectional view of the Tandem master cylinder

Wheel cylinder and its types


There are two types of wheel cylinders are used. They are

1. One piston type
2. Two piston type



Wheel cylinder

It is located on the brake carrier plate in between the two brake shoes. This






Figure 6.4.1.5 (a) Arrangement of the wheel cylinder

BAE_ENG_Chapter_06.indd 101 12/20/2019 1:04:21 PM