Problem 2: Lower braking efficiency

S.No.	Reasons	Fixing methods
1	Oil leakages from the brake drum and brake shoes	Have to change the brake shoes. Moreover the oil leakage must be stopped.
2	Connections and adjustments are away	Have to be corrected Based on the manufactures advice
3	Master cylinder damage in the hydraulic brake system	Testing should be done to repair the fault
4	Air bubbles present in the hydraulic brake system	Air bubbles have to be removed by using brake bleeding method. Required quantity of brake oil has to be filled.
5	The cam used to move the brake is damaged	New cam should be fixed

Problem 3: Brake binding

S.No.	Reasons	Fixing methods
1	If the return spring in the brake shoes or brake pedal losses its stiffness or have broken	New springs should be affixed.
2	Lack of lubrication in attachments	Exactly, the attachments should be properly lubricated
3	The size of the brake pedal free play in the brake pedal is not correct	Re-correct it
4	Any problems in wheel cylinder	Have to repair by checking or need to replace new one.
5	Bypass port in the master cylinder may get blocked	Need to clean the blockages using compressed air.

Problem 4: Noise is occurred when the is brake is operating

S.No.	Reasons	Fixing methods
1	If there is loose in Wheel bearing	Need to remove the loose connections and fix it.
2	If the brake drum and brake shoes were released from its center.	Two parts should be corrected and fixed in the same center.
3	If the wheel hub in a brake drum may be loose.	Need to accelerate the brake drum well
4	There may be a chance of occurring vibration in the brake shoes if the return springs in the brake shoes are losses.	Have to change the return spring
5	Brake shoes may be loosen in a brake disc	Change the brake shoes and fix it proper.

BAE_ENG_Chapter_06.indd 118 12/20/2019 1:04:25 PM