


Figure 8.11 Front axle

8.11.1 Types of Front axle

1. Dead Axle
2. Live Axle

8.11.1.1 Dead axle

- It is a just dummy axle. It having no connections with engine. It has sufficient rigidity and strength to transmit the weight of the vehicle from the steering and brake system without differential and axle shaft.



8.11.1.2 Live axle

- Live axle is the one through which power is transmitted to the wheels by means of differential and axle shaft. In case of front wheel drive or in all wheel drive, the front axle will act as live axle.



8.12 Stub Axle

- Stub axle is a short axle. Stub axle are connected to the front axle by means of king pin. The front wheels are mounted on the stub axle.

BAE_ENG_Chapter_08.indd 160 12/10/2019 12:11:20 PM