


Figure 10.10.2 Lighting system

10.10.3 Direction indicating lamps

Lamps are provided at each front and rear corner of a vehicle. This allows the driver to signal an intention to turn left or right to the opposing vehicle as well as following vehicle. A lever operated turn switch is mounted in the steering column. The turn signal lever is moved up for a right turn and down for a left turn. A flasher unit is used to open and close the lighting circuit about 70 – 80

BAE_ENG_Chapter_10.indd 210 12/20/2019 1:10:28 PM