works with the steel rods. It is designed in such a way that it can able to change its length.

2.5 Types of Clutch

1. Single plate clutch
2. Multi plate clutch
3. Diaphragm clutch
4. Centrifugal clutch
5. Hydraulic clutch
6. Fluid flywheel clutch
7. Electric clutch

2.5.1 Single Disc or Plate Clutch

Construction

- Main components of single plate clutch are listed below:

1. Fly wheel
2. Clutch plate
3. Clutch lining
4. Pressure plate
5. Coil spring
6. Release lever
7. Clutch shaft
8. Release lever bearing

- Clutch plate is placed in between fly wheel and pressure plate.
- Centre of clutch plate is attached with clutch shaft.
- Coil spring is placed in between pressure plate and clutch cover.
- Release lever is attached with pressure plate.
- Clutch cover is attached with fly wheel with the help of bolt and nuts.




Figure 2.5.1 (a) Single plate clutch

BAE_ENG_Chapter_02.indd 18 12/20/2019 1:00:33 PM