





Inspection

- Clean all the parts by kerosene.
- Inspect the, steering wheel steering shaft and worm gear for any damage.
- Inspect the cross shaft and drop arm.

BAE_Practical.indd 237 12/20/2019 2:35:28 PM